

Aero Troll

User's Manual Supplement
v0.3.0b

by

Martin C. Hegedus

December 6, 2013

Table of Contents

INTRODUCTION	1
Intent	1
What's New	1
LICENSE	2
INSTALLATION	3
BASIC EXAMPLE (NACA 0012).....	3
Startup.....	4
Main Menu Bar.....	5
Problem Specification.....	5
First Off Surface Grid Spacing Determination.....	6
Geometry Setup	8
Initial CFD Setup.....	15
CFD Gridding.....	20
View Translation and Zooming.....	32
CFD Run Setup.....	34
CFD Execution.....	40
BASIC CONCEPTS	54
Views	54
Segments.....	56
Line.....	56
Circular Arc	57
Elliptical Arc.....	58
B-Spline	59
Cubic Spline.....	61
Stretching and Point Distribution.....	62
Breaks	64
Adding Breaks	64
Editing Breaks.....	65
Gridding.....	66
Sub Steps.....	72
Xi Volume and Slope.....	75
Spread Start and Spread End.....	82
Average Volume Weighting.....	85
CFD Execution Settings.....	87
B.C. Settings	87
Time Stepping Values.....	88
CFD Display Settings	89
Plotting Contours	90
WEDGE	91
Problem Specification.....	93
Geometry Setup	93
Initial CFD Setup.....	101
CFD Gridding.....	107
CFD Run Setup.....	126

CFD Execution.....	137
MULTI-ELEMENT AIRFOIL	147
Problem Specification.....	147
Slat Geometry	149
Main Geometry	161
Flap Geometry	176
Initial CFD Setup	182
CFD Gridding	184
CFD Run Setup.....	216
CFD Execution.....	219
COMPONENTS	227
Nose	228
Notes	231
Airfoil.....	232
NACA Airfoil Description.....	232
User Defined 2D Shape	234
Menu Items	234
Component Fields.....	235
NACA Input Section.....	236
2D Geometry Input Section	237
AT_Airfoil_CFD.....	239
Menu Items	239
Commands	240
Input	240
Global Fields.....	241
Grid Fields	241
CFD Fields.....	242
Display Fields	244
CFD Grid Group (Airfoil).....	246
Menu Items	247
Commands	247
Vol. Grid	248
View	248
Settings.....	249
Grid Type Field.....	250
Surface Grid Fields	250
Volume Grid Fields.....	251
CFD Input Fields.....	253
CFD 2D Grid Block	254
Menu Items	254
Commands	255
View	256
Settings.....	257
Surface Grid Fields	257
Volume Grid Fields.....	258
CFD Input Fields.....	258

Exec AT CFD Dialog.....	259
Exec AT CFD Dialog Fields.....	259
Exec AT CFD AT Cntrl Fields.....	260
Exec AT CFD Run Cntrl Fields.....	261
Exec AT CFD Flow Field Fields.....	263
Exec AT CFD Resid Fields.....	265
Exec AT CFD Turb Fields.....	267
Exec AT CFD For+Mom Fields.....	269
Exec AT CFD History Fields.....	271
TOOLS/CALCULATORS.....	272
Standard Atmosphere.....	273
Y+.....	275
Isentropic.....	276
Shock.....	278
Expansion.....	280

INTRODUCTION

Intent

Aero Troll is a preliminary aerodynamic analysis tool with a graphical user interface. The goal of Aero Troll is to allow a user to describe and carry out aerodynamic analysis on simplified geometries. The tool supports education, academic aerodynamic analysis, and verification and validation efforts. The software was created to broaden my knowledge of software development and aerodynamic modeling. It is hoped that the tool will be helpful to others. Currently the code interfaces with a 2D Reynolds Averaged Navier Stokes solver, PANAIR (A502), and a hypersonic impact method.

Aero Troll is available for Linux (32 and 64-bit) and Windows XP. Aero Troll has had limited testing on Windows OSes other than XP.

All the required libraries have been included in the Aero Troll distribution. Aero Troll requires Java 1.5 or later to be installed.

What's New

The biggest addition to Aero Troll is a 2D Reynolds Averaged Navier Stokes (RANS) solver. This manual describes how to run the 2D RANS method along with some, but not all, changes. To run PANAIR and the impact method, the user is directed to the version 0.2.0b manual. It should be noted that the previous manual is outdated to some extent but hopefully the user can figure things out. Hopefully a future manual will be more complete.

New features:

- 1) 2D RANS solver
- 2) Printing
- 3) Scripting tool
- 4) Additional view capabilities
- 5) Screen snapshots
- 6) Contour plotting
- 7) Tools/Calculators
 - a) Standard Atmosphere
 - b) y^+
 - c) Isentropic
 - d) Shock
 - e) Expansion
- 8) Components
 - a) Airfoil
 - b) Nose
 - c) Notes

The scripting tool is not described in this manual and is left for a latter date.

LICENSE

Aero Troll License

Copyright (c) 2008-2013 Martin C. Hegedus.
All Rights Reserved.

Copying, reproduction, distribution, or publication of Aero Troll software is prohibited, unless expressly authorized by Martin C. Hegedus. Aero Troll must be obtained from www.hegedusaero.com or an authorized distributor.

This program and components are distributed in the hope that they will be useful, but **WITHOUT ANY WARRANTY**; without even the implied warranty of **MERCHANTABILITY** or **FITNESS FOR A PARTICULAR PURPOSE**. The software is offered "AS IS". Martin C. Hegedus and those associated with the development and distributions of any part of Aero Troll will not be liable to any party for any direct, indirect, special, incidental, or consequential damages arising out of any use of this software.

While every attempt has been made to identify and remove programming errors within the software, there remains a high probability that programming errors remain. It is possible that some of these errors could cause the results of an analysis to be incorrect. In addition, the analysis results may also be affected by other identified, unidentified, and unknown uncertainties and errors. The causes of these uncertainties and errors are, but are not limited to, physical approximation, physical modeling, geometry modeling, round-off, iterative convergence, discretization, and incorrect input.

Aero Troll and associated components are distributed **WITHOUT ANY WARRANTY** that usage, errors, assumptions, uncertainties, or any other aspect associated with Aero Troll, its components, and its analysis methods are documented or that documentation is accessible to the end user.

It is the responsibility of the end user to accept all analysis answers with **GREAT CAUTION** and **SKEPTISM**.

Aero Troll uses the following libraries, applications, and code:

PDAS PANAIR A502-ht2
PDAS NACA456
PDAS "Properties of the Standard Atmosphere"
JOGL 2.0-rc11
JavaPlot 0.4.0
gnuplot 4.6.3
CGNS 3.1.4
Jython 2.5.3

The licenses for these libraries and applications can be found by selecting the **About** menu item under Aero Troll's **Help** menu. The complete license is also in the Aero Troll directory.

INSTALLATION

Two compressed archives exist. One of the archives, AeroTroll_v030b.tgz, is tarred and gzipped. The other archive, AeroTroll_v030b.zip, is zipped. Please uncompress the one appropriate for you. Inside the uncompressed directory are four run scripts; AeroTroll_win.bat, AeroTroll_win64.bat, AeroTroll_lin, and AeroTroll_lin64. Using the run script appropriate for your system will start the Aero Troll application. The application does not need to be installed by means of a script or install wizard. Unpacking it is enough. The scripts do expect java to be in the execution path. The scripts can be customized with a text editor. Currently a Mac version of Aero Troll for CFD does not exist.

BASIC EXAMPLE (NACA 0012)



A NACA 0012 analysis will demonstrate the basic CFD usage of Aero Troll. For this case the freestream conditions will be Mach 0.5, angle of attack 2.0 degrees, and a Reynolds number of 3.0×10^6 based on the chord length. A Navier Stokes run will be chosen with the Spalart Allmaras turbulence model. This example will get a user started; however it will not demonstrate the full capabilities. Some of the capabilities and components will be described in later sections and examples. Other capabilities will need to be discovered by the user or by talking with others. It is also not the intent to teach the user the ins and outs of CFD. For that, the user is referred to literature and the internet.


Before the user can search for relevant information about the method, the user must know something about the CFD method used by Aero Troll. The CFD method used by Aero Troll is a compressible implicit central difference method for the Reynolds Averaged Navier-Stokes (RANS) equations in conservation law form for a calorically perfect gas and for structured overlapping (Chimera) grids. A scalar artificial dissipation method is used. The method employed by Aero Troll is first order accurate in time and second order accurate spatially. Both constant and local time stepping methods are available. Wall functions and Mach number preconditioning are not available at this time. Since Mach number precondition is not implemented, very low Mach number runs will not converge well and the results may be inaccurate due to numerical dissipation.

It should be noted, for the current version of Aero Troll, only the geometry and input parameters are saved. The solution is not saved. Therefore, CFD restarts can not be done once Aero Troll is exited.

Startup

To start Aero Troll under Windows, double click on the AeroTroll_win run script. Under Linux, execute the AeroTroll_lin script (or the AeroTroll_lin64 script for a 64-bit Linux box) at the command line. The license will be shown. Please read it and, if the terms and conditions are acceptable, select the **Accept** checkbox and click the **OK** button. Once accepted, the license window will not be displayed at startup in the future. If the license terms and conditions would like to be viewed at a subsequent time please select the **About** menu item under the **Help** menu.

Once started, the **Aero Troll** window will be displayed. This window is shown below.



At the top of the window is the main menu bar. Below and to the left of the main menu bar is the **Components** panel. The **Components** panel is the area where geometry components will be shown as nodes in a hierarchical tree. The hierarchical tree will be referred to as the component tree. To the right of the **Components** panel is the main

display panel. The width of the **Components** panel and main display panel can be adjusted by selecting the divider, which separates the two panels, and moving the divider left or right.

Main Menu Bar

To save an Aero Troll session, select the **Save As...**, or **Save** menu item under the **File** menu. The Aero Troll session file will be saved as an ASCII XML file. Only the geometry and input parameters are saved in the current version of Aero Troll. The solution is not saved. Therefore, solution restarts can not be done once Aero Troll is exited. To open a session file, select the **Open** menu item under the **File** menu. If a model already exists in Aero Troll, the newly opened model will be appended to the existing model.

To exit Aero Troll, select the **Quit** menu item under the **File** menu. After the **Quit** menu item is selected, a dialog box will appear which asks for confirmation. If the action is confirmed, Aero Troll will quit immediately. It is up to the user to save any work before Aero Troll is exited. Quitting Aero Troll will not automatically save the current session.

Next to the **File** menu is the **Edit** menu. The **Edit** menu allows the user to cut and copy components by selecting a component in the component tree and then selecting the **Cut** or **Copy** menu item. To paste a component, select the node in the component tree under which the component will be pasted and select the **Paste** menu item. If the component to be pasted is not allowed under the selected node, the **Paste** menu item will be disabled. The **Edit** menu also allows the user to unselect the auto close check box in all PANAIR and CFD execution windows.

The **View**, **Plot**, and **Tools** menus will be described in a later section.

To view the terms and conditions of the Aero Troll license, select the **About** menu item under the **Help** menu.

Problem Specification

The guiding principle behind the design of Aero Troll is to create an aerodynamic analysis system based on a component buildup approach which allows a user to quickly experiment with a variety of geometries and analysis approaches. The goal of the tool is to predict preliminary aerodynamics for these geometries and to determine the strengths and weaknesses of analysis methods. An additional goal for Aero Troll is to run on desktops, laptops, and high end workstations under a variety of operating systems. Well, that is the guiding principle. Aero Troll is still a work in progress!


This Aero Troll User's Guide Supplement will focus on the CFD aspect. Currently, only the Airfoil component can have a CFD analysis method attached to it. For additional information about Aero Troll, the user is referred to the version 0.2.0b User's Manual.

A key aspect of Aero Troll is the component building blocks. To summarize the usage, the user creates an analysis base component and then populates the analysis base component with geometry components and CFD components. There are two types of CFD components; 1) CFD analysis components and 2) CFD grid components. In general, only one CFD analysis component is created. However, multiple grid components can be, and frequently are, created. The CFD grid components are attached as sub components to the CFD analysis component for which they apply. Geometry components are then linked to a CFD analysis component. Once geometry components are linked to a CFD analysis component, they must also be linked to a CFD grid component. This informs the CFD grid component that it is responsible for creating a grid around that geometry. CFD analysis, CFD grid, flow condition, and reference values are then specified for the various components. Finally, the user executes the analysis base component and views the results.


The remainder of this example, and the next two, will give an introduction to this process and terminology.

First Off Surface Grid Spacing Determination

Before a geometry is set up and an analysis is run, the off surface grid spacing needs to be determined for the NACA 0012 grid using the y^+ tool. To open the tool, select the y^+ menu item under the **Tools** menu.



The y^+ tool is shown below.



The screenshot shows a software window titled "Y+" with a blue border and a close button in the top right corner. The window is divided into two main sections: "Input:" and "Output:".

Input:


- Reynolds Number:** A text input field.
- Reference Length:** A text input field followed by a dropdown menu currently set to "ft".
- x:** A text input field followed by a dropdown menu currently set to "ft".
- y+:** A text input field.

Output:

- Re_x:** A text input field.
- y:** A text input field followed by a dropdown menu currently set to "ft".

The Reynolds number is set to 3.0×10^6 and the reference length to 1.0 since that will be the chord length of the airfoil. The first grid spacing when using the Spalart Allmaras turbulence model should reflect a y^+ value of 1.0 or less at a reasonable "x" location on the airfoil. The selection of length units (feet, inches, meters, etc) can be confusing. If the units of the geometry are known, then it's straight forward. If the units of the geometry are unknown, then the user arbitrarily chooses length units for the problem and insures they are used consistently throughout the problem. If the airfoil was N "unknown units" long, then arbitrary units can be chosen for the airfoil and substituted in for the "unknown units" placeholder. For example, the length units can be assumed to be feet, inches, meters, etc. for the chord. Once the decision is made, all the length based units set in Aero Troll must have the same units. They must be consistent. Since the units of the airfoil chord length are unknown for this fictitious example, the units will be arbitrarily assumed to be feet.

The first step in using the tool is to set the Reynolds number, reference length, and the y^+ value in the y^+ tool. The tool with the updated fields is shown below.




The screenshot shows the Y+ tool interface with the following input and output fields:

Input:	
Reynolds Number	3e6
Reference Length	1 ft
x	ft
y^+	1

Output:	
Re_x	
y	ft

The final step is to set the x location at which the first off surface grid spacing will be calculated. In general, this is more of an art than a science. For this example, the x location will be set to 0.05. Once the user has entirely completed this CFD example, the user can go back and try different off surface grid spacing values to see what happens. Once the x value has been set, the tool will look as follows.



The screenshot shows the Y+ tool interface with the following input and output fields:

Input:	
Reynolds Number	3e6
Reference Length	1 ft
x	0.05 ft
y^+	1


Output:	
Re_x	150000.000000000003
y	6.475413537230505E-6 ft

The first off surface grid spacing will be taken as 6.5E-6. The y^+ tool can now be closed by selecting the X in the upper right and corner of the window frame.


Geometry Setup

Now that the first off surface grid spacing has been determined, the geometry can be set up.

To start the process, the user creates an analysis base component and adds it to the component tree by right clicking in the white portion of the **Components** panel and then selecting the **AT Analysis** menu item under the **Add** submenu of the component tree popup menu. This is shown in the figure below.




Once an AT Analysis component is created the analysis component can be populated with additional components. To attach a component to an AT Analysis component, right click on the AT Analysis component tree node to show the component popup menu and select one of the geometry components from the **Add** menu. This is shown in the figure below. Currently, only the Airfoil geometry component can have a CFD analysis bound to it.




After the component has been selected from the **Add** menu, a dialog box will appear requesting a name for the component. The default can be accepted or a new name entered. The **Rename** menu item of the component popup menu can be used to rename the component at a later time. Once the component is created it will be shown in the Main Display panel, assuming the AT Analysis component is active (active base components are described in the Views section below).

After the component is created, the component parameters can be modified by editing the component. To edit the component, right click on the Airfoil component node and select the **Edit** menu item in the component popup menu.




Once the **Edit** menu item is selected the Edit Window with an edit panel for the Airfoil component will be displayed.




To modify the component, change an entry in one of the text fields or change the selection of a check box or radio button. Once all the modifications have been made, select the **Accept** button to update the component with the new values. An error dialog box will be displayed if a modification is unacceptable. Select the **Revert** button to revert the entries to the previous values accepted values. The Edit Window can contain multiple edit panels. To update all the edit panels, select the **Accept All** button, or to revert all the panels, select the **Revert All** button.

For this example, the number of grid points on the top and bottom along with the clustering near the leading and trailing edge will be changed. The number of points should be changed from 101 to 151. The leading and trailing edge distribution should be changed from **Float** to **Delta % of Avg** set to 20%. This means the first (leading edge) and last (trailing edge) grid spacing is set to 20% of the average. Technical note: the points are distributed with a TanH distribution (NASA CR 3313).

The figure below shows the current Airfoil settings with the changes circled in red.




The figure below shows the updated Airfoil.




It should be noted that the point distribution defined on the geometry is used for determination of the loads and not for determining the grid. The surface geometry points specified under the Airfoil component do not carry over to the CFD gridding component. But, hopefully, in the next version it will.

Initial CFD Setup


The next step in the analysis process is to create a CFD analysis component and a grid component for the analysis method. To do this, create an AT_Airfoil_CFD component by selecting it from the **Add** menu of the AT Analysis component.




Next, create a CFD Grid Group for the AT_Airfoil_CFD component by right clicking on AT_Airfoil_CFD component and selecting the CFD Grid Group component from the **Add** menu. The CFD Grip Group component is a type of grid component for calculating a grid about a geometry. An AT_Airfoil_CFD component can have multiple grid components attached to it. For this example only one grid component will be attached.




The next step is to link the AT_Airfoil_CFD method to the Airfoil. Link the AT_Airfoil_CFD component to the Airfoil component by clicking and holding the left mouse button while over the AT_Airfoil_CFD component and then dragging and dropping the AT_Airfoil_CFD on to the Airfoil component. In general, an AT_Airfoil_CFD method can be linked to multiple airfoils components. An example would be the slat, main, and flap elements for a multi-element airfoil. However, only one airfoil is created and analyzed in this example.



Now that the AT_Airfoil_CFD method and Airfoil are linked, the Airfoil component can be linked to the CFD Grid Group. To accomplish this, click and hold the left mouse button while over the Airfoil component, which is attached to the AT_Airfoil_CFD component, and then drag and drop the component on to the CFD Grid Group component. For this to work, the Airfoil component under the AT_Airfoil_CFD component, and not the Airfoil component under the AT Analysis component, must be clicked on.




Before an analysis is performed, the analysis methodology for the Airfoil component must be chosen. To select the analysis method for the Airfoil component, right click on the Airfoil component node in the components tree to show the component popup menu and then select the AT_Airfoil_CFD method under the **Analysis Type** submenu.




CFD Gridding


Now that the initial setup is done, a CFD grid must be built for the airfoil. Depending on the geometry, the process can be quite complicated. This example is a simpler case. However, it still takes some effort. To start this process, open the edit panel for the CFD Grid Group by right clicking on it and selecting the **Edit** menu item. The edit panel for the CFD Grid Group will be displayed.



Initially the volume grid type will be set to an H grid. Since the NACA 0012 has a rounded leading edge, the grid type should be changed to a C grid. The wedge example below will demonstrate an H grid. To make this change, select the C setting from the **Grid Type** combo box, as shown below in the red circle.




The current state of the CFD Grid Group edit panel is shown below. Notice that *For Segment*, as pointed out by the green arrow above, has been removed from the Surface Grid list.




Over the next few steps the dimensions and point placement will be specified for the C grid. Both the length of the C cut (Aft Length) and the off body distance (Zeta Grid) must be specified. The off body distance is the distance between the first grid layer and outer boundary. Also, the number and distribution of points must be set for the airfoil surface, C cut (Aft Length), and off body direction (Zeta Grid). For this example, both the C cut and off body length will be set to 100 units. Note that the airfoil chord for this example is 1 unit.

The next step is to set the **Aft Length** to 100 by changing the value circled in red below.



Next, the distribution of points along the bottom and top surfaces of the airfoil, along with the C cut, will be set. In general, the order they are set is unimportant. However, depending on how segments are connected, failures can occur. In which case, an error message will be displayed. For this example, first the airfoil points and then the C cut will be set. To set the distribution of the bottom surface, right click on *Airfoil::Bottom Surface* and select the **Edit Segment** menu item.



The edit window for the segment will appear.

The image shows a dialog box titled "Segment" with a blue border and a close button in the top right corner. The dialog contains several input fields and radio button options. The "Total Length" field is set to 1.0190770438967127, "Average ds" is 0.2547692609741782, and "# of Points" is 5. Under "Beginning Connection", the "Float" radio button is selected, and the "Connect" checkbox is checked. The "Ending Connection" section also has "Float" selected and "Connect" checked. The "Delta S", "Delta %", and "Delta % of Avg" fields are set to 0.2547692609741782, 25.0, and 100.0 respectively for both beginning and ending connections.

Field	Value
Total Length	1.0190770438967127
Average ds	0.2547692609741782
# of Points	5
Beginning Connection	
Float	<input checked="" type="radio"/>
Delta S	<input type="radio"/>
Delta %	<input type="radio"/>
Delta % of Avg	<input type="radio"/>
Connect	<input checked="" type="checkbox"/>
Ending Connection	
Float	<input checked="" type="radio"/>
Delta S	<input type="radio"/>
Delta %	<input type="radio"/>
Delta % of Avg	<input type="radio"/>
Connect	<input checked="" type="checkbox"/>

Buttons: OK, Cancel, Accept, Revert


Set **# of Points** to 151 and select the **Delta % of Avg** radio button for the beginning and ending connections. Next, set the **Delta % of Avg** for both to 20%. Then select the **OK** button.

The image shows a 'Segment' dialog box with the following configuration:


Field	Value
Total Length	1.0190770438967127
Average ds	0.0067938469593114
# of Points	151
Beginning Connection	
Float	<input type="radio"/>
Delta S	<input type="radio"/> 0.0013587693918622
Delta %	<input type="radio"/> 0.1333333333333333
Delta % of Avg	<input checked="" type="radio"/> 20.0
Connect	<input type="radio"/> Fixed <input checked="" type="checkbox"/>
Ending Connection	
Float	<input type="radio"/>
Delta S	<input type="radio"/> 0.0013587693918622
Delta %	<input type="radio"/> 0.1333333333333333
Delta % of Avg	<input checked="" type="radio"/> 20.0
Connect	<input type="radio"/> Fixed <input checked="" type="checkbox"/>

Buttons: OK, Cancel, Accept, Revert


Repeat the above instructions for the *Airfoil::Top Surface* segment. Then open the edit window for the Aft Segment and set # of Points to 151 and select the **Connect** radio button for beginning connection. This will connect the beginning grid spacing for the Aft Segment to the trailing edge of the airfoil. Then click the **OK** button.




Next, right click on the *Geometric(S):[0]* element in the Zeta Grid list under the Volume Grid Input section to display the segment menu and select the **Edit Zeta Segment** menu item.



The edit window for the segment will be displayed.




Set **Length** 100, the **Number of Nodes** to 151, and **ds[0]** to 6.5E-6 and then select the **Accept** button. The value for **ds[0]** is the first off surface grid spacing determined using the y^+ tool at the beginning of this example. The segment edit window should look like the following figure.




To close the segment edit window, select the **OK** button.

Next, the boundary conditions must be set. To do this, scroll to the bottom of the CFD Grid Group edit panel to the CFD Input section. For the **Surface B.C.** combo box, select


Auto. For the **Farfield B.C.** combo box, select **Characteristic**. The CFD Grid Group edit panel CFD Input section should look as follows.



Next, create the grid by selecting the **Calculate Grid** menu item from the **Commands** menu in the CFD Grid Group edit panel.



The main window will display the grid.




Congratulations a grid has been created!


View Translation and Zooming

Now that the grid is created, it's time to check it out. One thing must be explained first. The user can translate and zoom the image, but the rate at which this is done is based on a translation scalar and a characteristic length of the entire geometry and grid. Since the grid is very large, compared to the airfoil, as one zooms in closer to the airfoil the rate at which translation and zooming occurs increases in speed. Therefore, the user will need to reset the translation scalar to a lower value at some point. This is very much an art at this time and the user will need to get accustomed to it. One of the pitfalls of this method is if the scalar is set to a small value to accommodate a large grid and the grid is then removed or invalidated, the translation and zooming becomes very slow. It is up to the user to realize that the translation scalar needs to be reset to a larger value.

To set the translation scalar, select the **Trans. Scaler** menu item under the **View** menu.



The Translation Scalar window will appear.




Set the translation scalar to a smaller value to move slower or a larger value to move faster.

Returning to view manipulation, the Main Display panel allows the user to translate, rotate, and zoom in and out. To translate the image, hold down the left mouse button and move the mouse in the direction the image should be translated. To rotate the image, hold down the right mouse button and move the mouse forward or backward to rotate the image about the x axis of the screen. Moving the mouse right or left will rotate the image about the y axis of the screen. To zoom the image, hold down the middle mouse button and move the mouse forward to zoom out of the image or move the mouse backward to zoom into the image.


The view for the Main Display panel can be reset to one of six predefined views (top, bottom, right, left, front, and back) by selecting the view from the **View** menu located in the main menu bar.

CFD Run Setup

Now that the grid has been inspected, it is time to modify the values associated with the run parameters for the CFD case. To do this, right click on the AT_Airfoil_CFD component and select the **Edit** menu item. Then change the solution methodology by selecting the **Turb (SA)** radio button in the AT_Airfoil_CFD edit panel. Next, change the CFL number to 90. These changes are highlighted below in red.




Selecting the **Turb (SA)** radio button will specify the run as a Reynolds Averaged Navier Stokes (RANS) solution using the Spalart Allmaras turbulence model. One might ask “How was the CFL value of 90 chosen?” The answer is through trial and error. A low value was initially used and then subsequent higher values were chosen until an optimum value was found. The next step is to set the left hand side (LHS) matrix solver methodology (LHS) for the xi and zeta direction.




Initially the LHS matrix solution methodology is set to the MDADI (Modified Diagonal Alternating Direction Implicit) method, but for this example it will be set to the ADI (Alternating Direction Implicit) method. In fact, for all the examples using a C or H grid it is set to ADI. The reason for this selection is that the MDADI and DADI (Diagonal Alternating Direction Implicit) methods make an approximation for the viscous terms which cause the methods to have difficulty converging on the fine grid spacing at the C cut. This approximation does not exist for the ADI method.


The next step will be to change the iteration points at which information from the CFD calculation is passed to the graphical user interface. To access the fields for this, change the AT_Airfoil_CFD input interface from CFD to Display.




In the AT_Airfoil_CFD Display input interface, set **Force Iterations** to 10 and **Update Iterations** to 20. The integrated force values will be shown once every 10 iterations and the Main Display window will be updated with the CFD solution once every 20 iterations.



Once this is completed, the values associated with an analysis, such as flow conditions and reference values, are changed. To accomplish this, open the Analysis edit panel by right clicking on the AT Analysis component node and selecting the **Edit** menu item under the AT Analysis component popup menu. The AT Analysis edit panel for the AT Analysis component is shown below.




For this example, the angle of attack will be set to 2 degrees, the default Mach number will be kept at 0.5, and the Reynolds number per length will be set to $3e6$. The Reynolds number per length must have the same units as the grid. For example, if the airfoil was 3 units long then the Reynolds number per length would be $1e6$. However, for this case, the chord is conveniently one unit long.




CFD Execution


Once the required values have been set, the solution can be executed by selecting the **Execute** menu item under the **Commands** menu.




The Exec AT CFD Dialog will be shown. This is the main interface for executing and monitoring a CFD run.




At the top are various tabs to select panels for information display and entry. At the bottom are a set of buttons to control the execution of the CFD case. Since the CFD case is initially in run mode, the only control option available is for pausing the execution. Shown below is the Resid panel.




The progress of the convergence can be monitored from the Resid panel. This will probably be the panel most frequently viewed. To plot the convergence history, select the **Plot This** button to view the convergence history of the current grid. The **Plot All** button will plot the convergence history for all the grids. For this case there is only one grid. Therefore, the **Plot This** and **Plot All** buttons perform the same function. Gnuplot, an external application, is used for plotting and is included with Aero Troll. The following plot shows the residual after about 55 iterations have elapsed. Note that, for some unknown reason, gnuplot plot under Windows can take a bit of time to start up.




The following plot shows the residual after 1000 iterations have elapsed.




The following figure shows the For+Mom panel.




The following plot shows the normal force coefficient after about 105 iterations have elapsed.




The following plot shows the normal force coefficient after 1000 iterations have elapsed.




The contour plot for the pressure, non-dimensionalized by the freestream pressure, will be shown in the Main Display panel. The following figure shows the contour plot after 1000 iterations.




To hide the wire frame, return to the edit panel for the CFD Grid Group panel and select the **Hide Wireframe** menu item under the **View** menu.




The main window will look as follows. Note the magenta dot at the trailing edge, as indicated by the red circle. Well, the dot appears as a single dot, but is actually two.



Zoom into these dots. The Trans. Scalar will need to be changed to a lower value for a slower zooming speed.





These dots indicate where the max solution deltas are occurring over the last few iterations. To hide these dots, return to the edit panel for the CFD Grid Group panel and select the **Hide Max. Solution** menu item under the **View->Points** menu.



To show these points, or the other two classes, select the corresponding show menu item.

Select the **Results** button in the AT Analysis edit panel or the **Results** menu item in the AT Analysis component popup menu to view the integrated results. The AT Analysis Results panel, which is contained in the **Result** window, is shown below.





Scroll through the window to view the results.


This completes the example.

BASIC CONCEPTS

The following section introduces some basic concepts for Aero Troll. After the basic concepts are described, an example for a wedge and a multi-element airfoil will be given.

Views

The base component must be activated to view it in the Main Display panel. Only one base component can be active at a time. Select the **Activate** or **Deactivate** menu item from the base component popup menu to activate or deactivate the base component.



The Main Display panel allows the user to translate, rotate, and zoom in and out. To translate the image, hold down the left mouse button and move the mouse in the direction the image should be translated. To rotate the image, hold down the right mouse button and move the mouse forward or backward to rotate the image about the x axis of the screen. Moving the mouse right or left will rotate the image about the y axis of the screen. To zoom the image, hold down the middle mouse button and move the mouse forward to zoom out of the image or move the mouse backward to zoom into the image.

As mentioned under the NACA 0012 example, the rate at which this is done is based on a translation scalar and a characteristic length of the entire geometry and grid. Therefore, as one zooms in closer to the geometry the length scales of the objects seen in the screen might be much smaller than the overall length scale, in which case translation will occur at a fast rate. Therefore, the user will might need to reset the translation scalar to a lower value. To set the translation scalar, select the **Trans. Scalar** menu item under the **View** menu.

The view for the Main Display panel can be reset to one of six predefined views (top, bottom, right, left, front, and back) by selecting the view from the **View** menu located in the main menu bar.

The user may also save views and set them at a later time. The user may also copy and paste views between various analyses.

Segments

Segments are Aero Troll's building blocks for describing geometry mold lines. An example of a mold line would be the outer surface of a 2D geometry.

Each segment begins at the end of the previous segment. Or, if the segment is the first segment, then the segment begins at a user specified point. The slope at the beginning and end of a segment can either be user specified or, if the segment allows it, a continuation of the adjacent segment. Whether the slope can be set or not, by either method, will depend on the degree of freedom for that segment. It is important to note that, currently, the slope of one segment can be implicitly determined from the end of another, but two segments can not be connected together such that the slopes of both segments at a connection point are determined from each other, in other words, the segments are completely coupled. For example, the end slope of one segment can not be determined from the start slope of the next segment and, at the same time, the start slope of the next segment determined from the end slope of the previous segment.


Five types of segments are available

- 1) Line
- 2) Circular Arc
- 3) Elliptical Arc
- 4) B-Spline
- 5) Cubic Spline

Each segment will be described below.

Line

The following figure shows the input dialog for the line when the line is first created. Another similar input dialog is used when a preexisting line is edited. The difference between the two input dialogs is that the edit input dialog has **Accept** and **Revert** buttons in addition to the **OK** and **Cancel** buttons.




The line segment is a simple segment which connects a beginning point to an end point with a straight line. The beginning point is either the end point of the previous segment or a user specified point if a previous segment does not exist. The line segment does not allow the user to explicitly set the beginning or end slope.

The line segment has the following parameters.

End Pt: The x and y coordinates of the end point.

Circular Arc

The following figure shows the input dialog for the circular arc when the circular arc is first created. Another similar input dialog is used when a preexisting circular arc is edited. The difference between the two input dialogs is that the edit input dialog has **Accept** and **Revert** buttons in addition to the **OK** and **Cancel** buttons.



The circular arc segment connects a beginning point to an end point with a circular arc. The beginning point is either the end point of the previous segment or a user specified point if a previous segment does not exist. The circular arc segment allows the user to explicitly set either the beginning or end slope, but not both.

The circular arc segment has the following parameters.

End Pt: The x and y coordinates of the end point.


Third Constraint: This set of radio buttons allows the user to specify how to set the required slope parameter for the circular arc. If an option is not available then the corresponding radio button will be disabled. For the case shown by the figure above, a segment did not exist after the circular arc segment; therefore the **Connect End Slope** radio button is disabled.

Slope: The input fields for specifying the slope by the user. Both dx and dy can not be simultaneously zero. The dx and dy values are scaled by the inverse of the magnitude, i.e. $1.0/\sqrt{dx^2+dy^2}$; therefore the values are independent of the magnitude.

Clockwise: Specifies if the circular arc should be drawn in a clockwise or counter clockwise direction when connecting the beginning point to the end point.

Elliptical Arc

The following figure shows the input dialog for the elliptical arc when the elliptical arc is first created. Another similar input dialog is used when a preexisting elliptical arc is edited. The difference between the two input dialogs is that the edit input dialog has **Accept** and **Revert** buttons in addition to the **OK** and **Cancel** buttons.



The elliptical arc segment connects a beginning point to an end point with an elliptical arc. The beginning point is either the end point of the previous segment or a user specified point if a previous segment does not exist. The elliptical arc segment requires the user to set, either implicitly or explicitly, both the beginning and end slopes.

The elliptical arc segment has the following parameters.

End Pt: The x and y coordinates of the end point.

Start Slope Type: This set of radio buttons allows the user to specify if the slope at the start of the elliptical arc is set by the user or obtained from the previous segment. If a previous segment does not exist then the radio button will be disabled.

End Slope Type: This set of radio buttons allows the user to specify if the slope at the end of the elliptical arc is set by the user or obtained from the next segment. If a following segment does not exist then the radio button will be disabled. In the case shown for the figure above, the segment was the last one and therefore

Start Slope: The input fields for specifying the start slope by the user. Both dx and dy can not be simultaneously zero. The dx and dy values are scaled by the


inverse of the magnitude, i.e. $1.0/\sqrt{dx^2+dy^2}$; therefore the values are independent of the magnitude.

End Slope: The input fields for specifying the end slope by the user. Both dx and dy can not be simultaneously zero. The dx and dy values are scaled by the inverse of the magnitude, i.e. $1.0/\sqrt{dx^2+dy^2}$; therefore the values are independent of the magnitude.

Clockwise: Specifies if the elliptical arc should be drawn in a clockwise or counter clockwise direction when connecting the beginning point to the end point.

B-Spline

The following figure shows the input dialog for the b-spline when the b-spline is first created. Another similar input dialog is used when a preexisting b-spline is edited. The difference between the two input dialogs is that the edit input dialog has **Accept** and **Revert** buttons in addition to the **OK** and **Cancel** buttons.



The b-spline segment connects a beginning point to an end point with a b-spline. The beginning point is either the end point of the previous segment or a user specified point if a previous segment does not exist. The b-spline segment requires the user to set, either implicitly or explicitly, both the beginning and end slopes. In addition, the user must set a control value for both the beginning and end of the segment.

The b-spline segment has the following parameters.

End Pt: The x and y coordinates of the end point.

Start Slope Type: This set of radio buttons allows the user to specify if the slope at the start of the b-spline is set by the user or obtained from the previous segment. If a previous segment does not exist then the radio button will be disabled.

End Slope Type: This set of radio buttons allows the user to specify if the slope at the end of the b-spline is set by the user or obtained from the next segment. If a following segment does not exist then the radio button will be disabled. In the case shown for the figure above, the segment was the last one and therefore

Start Slope: The input fields for specifying the start slope by the user. Both dx and dy can not be simultaneously zero. The dx and dy values are scaled by the inverse of the magnitude, i.e. $1.0/\sqrt{dx^2+dy^2}$; therefore the values are independent of the magnitude.


End Slope: The input fields for specifying the end slope by the user. Both dx and dy can not be simultaneously zero. The dx and dy values are scaled by the inverse of the magnitude, i.e. $1.0/\sqrt{dx^2+dy^2}$; therefore the values are independent of the magnitude.

Start Cntrl: The control value for the slope at the start of the b-spline. This term has the effect of emphasizing the importance of the slope. The higher the value, the longer the slope will be maintained.

End Cntrl: The control value for the slope at the end of the b-spline. This term has the effect of emphasizing the importance of the slope. The higher the value, the longer the slope will be maintained.

Cubic Spline

The following figure shows the input dialog for the cubic spline when the cubic spline is first created. Another similar input dialog is used when a preexisting cubic spline is edited. The difference between the two input dialogs is that the edit input dialog has **Accept** and **Revert** buttons in addition to the **OK** and **Cancel** buttons.



The image shows a dialog box titled "Update Object" with a blue border and a close button in the top right corner. The dialog is divided into two main sections for "Start Slope" and "End Slope". Each section contains three radio buttons: "Input", "Connect", and "Float". The "Float" radio button is selected in both sections. Below the radio buttons are two input fields labeled "dx" and "dy". At the bottom of the dialog, there are two buttons: "OK" and "Cancel".

The cubic spline segment connects a set of points with a cubic spline. The first point is either the end point of the previous segment or a user specified point if a previous segment does not exist. The cubic spline segment requires the user to set, either implicitly or explicitly, both the beginning and end slopes.

Start Slope Type: This set of radio buttons allows the user to specify how the slope of the first point is set. The user can input the slope, set the slope from the previous segment, or let the slope float.

Start Slope: The input fields for specifying the start slope by the user. Both dx and dy can not be simultaneously zero. The dx and dy values are scaled by the

inverse of the magnitude, i.e. $1.0/\sqrt{dx^2+dy^2}$; therefore the values are independent of the magnitude.

End Slope Type: This set of radio buttons allows the user to specify how the slope of the last point is set. The user can input the slope, set the slope from the previous segment, or let the slope float.

End Slope: The input fields for specifying the end slope by the user. Both dx and dy can not be simultaneously zero. The dx and dy values are scaled by the inverse of the magnitude, i.e. $1.0/\sqrt{dx^2+dy^2}$; therefore the values are independent of the magnitude.

The process for adding points to the cubic spline segment is described under the multi-element airfoil example.

Stretching and Point Distribution

The stretching methodology for specifying point distributions comes from NASA CR 3313 and is used to distribute points along a 1D surface, i.e. a curve. The methodology relies on trigonometric and hyperbolic functions in addition to specifying a point spacing methodology at the ends. The actual point spacing at the end points can be specified, or the spacing can be allowed to float. Under some circumstances the end points for two point distributions can be connected such that the spacing automatically transitions smoothly between the point distribution before and after an end point.

A typical point distribution dialog for a segment is shown below.

The screenshot shows a dialog box titled "Segment" with a close button (X) in the top right corner. The dialog contains several input fields and radio buttons. The "Total Length" field is set to 6.299999999999806E-4. The "Average ds" field is set to 1.574999999999515E-4. The "# of Points" field is set to 5. Under "Beginning Connection", the "Float" radio button is selected. The "Delta S" field is set to 1.574999999999515E-4, "Delta %" is 25.0, and "Delta % of Avg" is 100.0. The "Connect" checkbox is checked and labeled "Fixed". Under "Ending Connection", the "Float" radio button is also selected, with "Delta S" set to 1.574999999999515E-4, "Delta %" at 25.0, "Delta % of Avg" at 100.0, and the "Connect" checkbox checked and labeled "Fixed". At the bottom, there are four buttons: "OK", "Cancel", "Accept", and "Revert".

Total Length: The length of the segment. This is an informational field and is not editable.

Average ds: The average delta length, i.e. $\{\text{Total Length}\} / \{(\# \text{ of Points}) - 1\}$. This is an informational field and is not editable.

of Points: The number of points to distribute over the segment, including the beginning and end point.

Beginning Connection

Float: Allow the point distribution at the beginning to float. The floating point distribution minimizes the growth (or reduction) of the grid spacing at the beginning point.

Delta S: Set the beginning grid spacing to the specified value. The specified input spacing most likely will not match the actual spacing formed by the distribution. The input spacing is an approximation and is used to set a derivative, i.e. slope, at the end point. The actual spacing is an integrated value, and, because of the non-linear nature of the equations, the actual spacing may not integrate to the specified spacing.

Delta %: Set the beginning grid spacing to a percentage of the total length. 100% equals the total length. As stated above, the specified spacing is an approximation and will not equal the actual spacing as determined by the distribution.

Delta % of Avg: Set the beginning grid spacing to a percentage of the average delta length. 100% equals the average ds. As stated above, the specified spacing is an approximation and will not equal the actual spacing as determined by the distribution.

Connect: Set the grid spacing approximation equal to the neighboring grid spacing approximation. If the distributions on both sides of a point are set to connect then the grid spacing is automatically determined to smoothly go through the point. If the distributions on both sides of a point are set to connect and both distributions are not fixed, then the point is allowed to float.

Ending Connection


The ending connection values are similar to the beginning connection values.

Breaks

In general, break points can be placed on a segment so that multiple point distributions can be specified for a line.

Adding Breaks

The following dialog shows the fields required for adding a break.




Total Length: The length of the segment. This is an informational field and is not editable.

of Points: The number of points for the default point distribution which is inserted on the segment over which the break acts.

S: The distance from the beginning at which the break is placed.

%: The percentage distance from the beginning at which the break is placed.

Editing Breaks



Min/Max S: The distance of the breaks or end points which bracket this break. The break can not overlay or be moved before the previous break or end point, nor can it overlay or be moved after the next break or end point.


Min/Max %: The distance, as a percentage of the total length, of the breaks or end points which bracket this break. The break can not overlay or be moved before the previous break, or end point, nor can it overlay or be moved after the next break or end point.

S: The distance from the beginning to which the break is moved. The break must be placed between the Min and Max S values.

%: The percentage distance from the beginning to which the break is moved. The break must be placed between the Min and Max % values.


Gridding

Aero Troll uses an overset grid, also known as a Chimera, approach to gridding. In an overset grid approach, a set of structured grids are created and linked together by interpolation coefficients which pass information from one grid to another. An overset grid for a multi element airfoil is shown below. The multi element airfoil is the final example of this manual.




In the image above, four grids are visible: 1) slat grid, 2) main wing grid, 3) flap grid, and 4) background Cartesian grid. The image above is the final grid product. To achieve this, first the individual grids need to be calculated. Then, points which lie inside the geometry of a component, or possibly close to it, are removed, or iblanked. Next, trilinear interpolation coefficients for the fringe, i.e. edge, points are determined.


The following images shows the multi element airfoil grid set before the hole punching (cutting and trimming) is done.



The next image shows both the cut and trimmed grid points in cyan and green respectively. The cut points lie within the geometry (which includes a tolerance distance (specified by the user) from the geometry edge). The trimmed points are a user specified number of layers trimmed away from the cut edge.



The next image shows the fringe points in blue.



As can be seen from the image above, fringe boundaries have two layers of points. The CFD method used by Aero Troll requires that the interpolation coefficients for the very outer layer of fringe points always be determinable. The second layer is not required but is beneficial. One fringe layer is required for the 2nd order flux stencil. Two fringe layers facilitate the artificial dissipation method. The fringe points for which required interpolation coefficients can not be found are called orphan points. In future versions of Aero Troll, for which higher order methods may be implemented, the number of requested fringe layers will increase.

Creating a grid set is challenging and very much of an art. Experimentation by the user is required to become proficient at generating a grid set.

At the moment, Aero Troll has two types of grids. One type of grid fits around objects and is called a body conforming grid. The second type is a background block grid. This discussion will focus on the grid generation parameters for the body conforming grids. Block grids and the other required input for the body conforming grids will be left to the examples.

The body conforming grid is created with an implicit hyperbolic grid generator which marches off the surface. Another type of body conforming grid generation method,

which is not implemented currently in Aero Troll, is an elliptical grid generator. In general, and in contrast to elliptical grids, a hyperbolic grid is easier to set the boundaries, is not as smooth, and can be more problematic in regards to the grid generation. When setting up a hyperbolic grid, the user must specify the surface grid, the spacing used when marching off the surface, and the grid generation parameters. This discussion will focus on some of the grid generation parameters and leave the other items to the examples.

A brief overview of the following grid generation settings will be:


- 1) Sub Steps
- 2) Xi Volume Smoothing
- 3) Xi Slope Smoothing
- 4) Zeta Spread Start
- 5) Zeta Spread End
- 6) Average Volume Weighting

The following settings will not be discussed and it is recommended they be left at the default settings.

- 1) Metric Multiplier
- 2) 2nd Order Dissipation.


To help with the discussion, the slat and main wing grids will be used. These cases are included in the examples directory.

The baseline slat grid from the multi element example, along with a table of the parameter values, is shown below.



Grid	Slat
Sub Steps	4
Xi Volume Smoothing	10.0
Xi Slope Smoothing	0.0
Zeta Spread Start	0.0%
Zeta Spread End	300.0%
Average Volume Weighting	0.0

The baseline main wing grid from the multi element example, along with a table of the parameter values, is shown below.




Grid	Main
Sub Steps	1
Xi Volume Smoothing	10.0
Xi Slope Smoothing	10.0
Zeta Spread Start	0.0%
Zeta Spread End	300.0%
Average Volume Weighting	0.6

Sub Steps

The number of sub steps, or sub iterations, is the number of iterations that occurs in the zeta (off body) direction for a xi (circumferential) grid line to be drawn. In general, the number of sub steps is 1. In other words, a grid line is drawn for each iteration. For geometries with a lot of curvature, more sub steps may be required so oscillations do not occur and/or zeta lines do not overshoot and cross one another. However, too many sub iterations will cause the grid to have difficulty changing direction and thus cross. Therefore, either too few or too many sub steps may cause the grid generation process to fail.


The slat grid will be used as an example. If the number of sub steps is set to 1, then the gridding will blow up and a solution is not found.

Two sub steps results in the following grid.



Grid	Slat
Sub Steps	2
Xi Volume Smoothing	10.0
Xi Slope Smoothing	0.0
Zeta Spread Start	0.0%
Zeta Spread End	300.0%
Average Volume Weighting	0.0


Ten sub steps results in the following grid.



Grid	Slat
Sub Steps	10
Xi Volume Smoothing	10.0
Xi Slope Smoothing	0.0
Zeta Spread Start	0.0%
Zeta Spread End	300.0%
Average Volume Weighting	0.0

Notice the higher amount of sub steps forces the zeta grid lines from the sharp lip and the trailing edge to squeeze together and attempt to intercept one another.

To get a better idea what occurs when the number of sub steps is set to one, the off body (zeta) marching length will be reduced. This is shown below.



Grid	Slat
Sub Steps	1
Xi Volume Smoothing	10.0
Xi Slope Smoothing	0.0
Zeta Spread Start	0.0%
Zeta Spread End	300.0%
Average Volume Weighting	0.0

As can be seen, the poor grid accuracy causes an oscillation to build.

Xi Volume and Slope

Because the grid generator for Aero Troll is an implicit method, the entire grid is marched forward by coupling together all the grid points on a xi surface. In other words, a point on a grid surface is marched to the next position by not only taking into account its normal vector, but also taking into account changes in the surrounding normal vectors. This is different than an explicit marching method which only accounts for the grid point normal vector and neglects changes caused by marching forward the surrounding grid point normal vectors and neglects what is occurring in the region of that point. Using an implicit method opens up the opportunity to change how the surrounding normal vectors


feedback to the normal vector of a grid point. This is where Xi Volume and Xi Slope come in. Setting these parameters to a value greater than zero will overemphasize how changes in a region affect the points of that region as they are marched forward. For example, if a cluster of points are trying to come together, thus shrinking the cell volumes, a positive value of Xi Volume will push the points apart. On the other hand, if the points are trying to spread apart, then a positive value of Xi Volume will pull together the points. In the same sense, if a set of zeta grid lines are trying to curve in a certain direction, positive values of Xi Slope will push the lines in the other direction.

A value of zero for either Xi Volume or Xi Slope indicates a modification to the feedback does not occur for that parameter.

In general, Xi Volume is modified first and then Xi Slope. The gridding process seems to be, in general, more robust for changes in Xi Volume.


The following examples illustrate the process. Since a xi grid surface is created using a coupled system, the interactions can be complex.

The following image is the baseline grid for the slat.



Grid	Main
Sub Steps	4
Xi Volume Smoothing	10.0
Xi Slope Smoothing	0.0
Zeta Spread Start	0.0%
Zeta Spread End	300.0%
Average Volume Weighting	0.0


The next images shows the result for increasing Xi Volume to 30.



Grid	Main
Sub Steps	4
Xi Volume Smoothing	30.0
Xi Slope Smoothing	0.0
Zeta Spread Start	0.0%
Zeta Spread End	300.0%
Average Volume Weighting	0.0

Notice that the grid lines emanating from the bottom slat surface between the lip and trailing edge are resisting being clumped together. Also notice that the grid lines at the trailing edge on the top side are resisting being pulled apart.


The following image shows the main wing cavity for Xi Volume of 5.



Grid	Main
Sub Steps	1
Xi Volume Smoothing	5.0
Xi Slope Smoothing	0.0
Zeta Spread Start	0.0%
Zeta Spread End	300.0%
Average Volume Weighting	0.6


The red dots above indicate that negative volumes, i.e. Jacobians, have occurred.

The following image shows the main wing cavity for Xi Volume of 10.




Grid	Main
Sub Steps	1
Xi Volume Smoothing	10.0
Xi Slope Smoothing	0.0
Zeta Spread Start	0.0%
Zeta Spread End	300.0%
Average Volume Weighting	0.6

As can be seen in the above image, the lines have been forced apart, however the lines are still sloppy in regards to the slope. To correct this, Xi Slope will be increased to 10.



Grid	Main
Sub Steps	1
Xi Volume Smoothing	10.0
Xi Slope Smoothing	10.0
Zeta Spread Start	0.0%
Zeta Spread End	300.0%
Average Volume Weighting	0.6

The next image shows what occurs at the leading edge of the main element when Xi Slope is increased to 20.




Grid	Main
Sub Steps	1
Xi Volume Smoothing	10.0
Xi Slope Smoothing	20.0
Zeta Spread Start	0.0%
Zeta Spread End	300.0%
Average Volume Weighting	0.6

Spread Start and Spread End

The spread start and end parameter allows for the user to specify how the grid spacing between points on a xi surface changes as the grid marches away from the surface. Spread end is a means by which the grid is forced to have equidistant spacing between the grid points at some distance from the surface. For example, if the value is set at 300% then at 3x the specified maximum off surface distance the grid is assumed to have equal spacing between grid points. If the value was 100%, then the last grid xi grid surface would have equal spacing. The spread start value specifies the point at which point redistribution starts. The amount of point redistribution which occurs is a weighted average that is a function of the distance between the start and end. For example, if the zeta distance is half way between the start and end, then the requested distance between


points is influenced by weighted average between 50% of the current xi grid spacing and 50% of the average xi grid spacing. If both the spread start and end are set to zero then spacing redistribution does not occur.

The following example shows the slat grid if the Spread End distance is 0%.



Grid	Slat
Sub Steps	4
Xi Volume Smoothing	10.0
Xi Slope Smoothing	0.0
Zeta Spread Start	0.0%
Zeta Spread End	0.0%
Average Volume Weighting	0.0


The following example shows the slat grid if the Spread End distance is 200%.



Grid	Slat
Sub Steps	4
Xi Volume Smoothing	10.0
Xi Slope Smoothing	0.0
Zeta Spread Start	0.0%
Zeta Spread End	200.0%
Average Volume Weighting	0.0

As can be seen, the grid lines spread out as zeta increases.

The following image shows the effects of changing the zeta spread start value. As can be seen, the spreading of the grid lines is delayed until off the surface by an amount.




Grid	Slat
Sub Steps	4
Xi Volume Smoothing	10.0
Xi Slope Smoothing	0.0
Zeta Spread Start	25.0%
Zeta Spread End	200.0%
Average Volume Weighting	0.0

Average Volume Weighting


The final parameter to be discussed is an average volume weighting. The value specifies the amount of the current versus neighboring values to use. It is a means of smoothing out the volume in local areas where the volume is a strong function of xi. This value is different than the Xi Volume parameter in the sense that it is more localized and is a function of the actual volume at a given xi grid line rather than changes which occur as the grid marches out. In other words, it is a parameter which affects the explicit rather than implicit behavior. A value of zero for the average volume weighting signifies that adjacent volumes should not be weighted into the volume calculation.

The following image shows the cavity grid using an average volume weighting of 0.0.



Grid	Main
Sub Steps	1
Xi Volume Smoothing	10.0
Xi Slope Smoothing	10.0
Zeta Spread Start	0.0%
Zeta Spread End	300.0%
Average Volume Weighting	0.0

The following image shows the cavity grid using an average volume weighting of 0.6.



Grid	Main
Sub Steps	1
Xi Volume Smoothing	10.0
Xi Slope Smoothing	10.0
Zeta Spread Start	0.0%
Zeta Spread End	300.0%
Average Volume Weighting	0.6

CFD Execution Settings

The following section gives a brief description of some CFD parameters used in the following examples. They will be described again when the CFD components are described.

B.C. Settings

Before a CFD job can be executed, the boundary conditions must be specified. Listed below are possible choices. Not all choices are available for every circumstance.

Far Field Boundaries

- Freestream:** The Freestream boundary condition will explicitly set the boundary to the freestream values.
- Characteristic:** The Characteristic boundary condition uses the Riemann variables determined from the freestream and the point just interior to the boundary to determine the values at the boundary. The Riemann variables are based on a wave equation representation of the Euler equations. Waves can travel from the interior points out the boundary and from the outside (freestream) into the interior. Based on this, the values at the boundary are determined. In general, this is the preferred far field boundary condition.
- Inlet/Outlet:** The Inlet/Outlet boundary condition sets the boundary value to either the freestream or to the point just interior to the boundary depending on the direction of the velocity vector. If the flow is coming into the boundary then the boundary is set to the freestream value. If the flow is exiting the boundary then the boundary is set to the flow values of the point just interior to the boundary.
- Fringe:** The Fringe boundary condition specifies that the far field boundary for the grid is a fringe boundary and must interpolate the values from another grid.

Surface Boundaries

- Auto:** The Auto boundary condition will set the surface to a slip boundary condition if the Euler equations are being used or to a no-slip boundary condition if the Navier Stokes equations are being used. Two boundary sub types are available. The Momentum sub type specifies that the momentum equations should be used to determine the flow values at the surface. This should be selected if the off body spacing is large. The Extrapolate sub type specifies that the flow values should be extrapolated from the values off the surface. This sub type should be used if the off body spacing is small. In general, the Extrapolate boundary condition is used for the Navier Stokes equations since the off body spacing tends to be very small.
- Slip:** The Slip boundary condition specifies that the velocity at the surface is not zero. Two boundary sub types are available; 1) Extrapolate and 2) Momentum. These are described in the Auto boundary condition description above.
- No Slip:** The No Slip boundary condition specifies that the velocity at the surface is zero. Two boundary sub types are available; 1) Extrapolate and 2) Momentum. These are described in the Auto boundary condition description above.

Time Stepping Values

There are two approaches to marching a solution forward: 1) global time stepping (dt), and 2) local time stepping, (CFL). The global time stepping approach marches all the

grid points forward in time by a uniform constant time step. This method is a time accurate method. The local time step will vary the time step for a grid point by the volume associated with that grid point. The larger the volume, the large the time step is. This method is not a time accurate method. The advantage of local time stepping is that it accelerates the convergence to steady state. It must be noted that the global and local time stepping approach may not necessarily converge on the same steady state solution since the equations for time are different between the two approaches. If the two methods give different solutions, then the time accurate approach is the physically correct method. However, frequently, the two approaches do converge on the same solution.

The screen capture below shows example settings for global time stepping approach. For this set of input, the user specifies the global time step, **dt**. The user can also set a low and a high bracketing value for the CFL number. Setting the **CFL min** or **CFL max** value to zero specifies that the low and/or high bracketing value is not used.

Iterations:	<input type="text" value="2500"/>				
Time Stepping	<input type="radio"/> CFL	<input checked="" type="radio"/> dt			
dt:	<input type="text" value="0.5"/>	CFL min:	<input type="text" value="0.0"/>	CFL max:	<input type="text" value="0.0"/>

The screen capture below shows example settings for local time stepping approach. For this set of input, the user specifies the local time step, **CFL**. The user can also set a low and a high bracketing value for the dt number. Setting the **dt min** or **dt max** value to zero specifies that the low and/or high bracketing value is not used.

Iterations:	<input type="text" value="2500"/>				
Time Stepping	<input checked="" type="radio"/> CFL	<input type="radio"/> dt			
CFL:	<input type="text" value="60.0"/>	dt min:	<input type="text" value="0.0"/>	dt max:	<input type="text" value="0.0"/>

CFD Display Settings

The following section describes the settings to modify the interval at which solution parameters are shown.

Resid Iterations:	<input type="text" value="1"/>		
Force Iterations:	<input type="text" value="20"/>		
Update Iterations:	<input type="text" value="100"/>		
Size of Max. Resid Pts	<input type="text" value="5"/>	# of Max. Resid Pts	<input type="text" value="200"/>
Size of Marked Pts	<input type="text" value="5"/>		

Resid Iterations: The interval at which the CFD residuals and solution deltas are passed to Aero Troll execution dialog.

Force Iterations: The interval at which the loads integrated by the CFD execution module are passed to the Aero Troll execution dialog.

- Update Iterations: The interval at which the Main Window contour plot is updated.
- Size of Max. Resid Pts: The size of the points in pixels which identifies the grid point location of the maximum residual.
- # of Max. Resid Pts: The number of iterations for which the location of the maximum residual is identified.
- Size of Marked Pts: The default size of the points in pixels which identifies cut, trimmed, boundary, fringe, upgraded, and orphan point.

Plotting Contours

The Plot menu for the main Aero Troll window allows for the user to select the contour type. The majority of contour types are non-dimensional. The following list shows the name of the contour type and how the value is non-dimensionalized. The contour values available from the menu will depend on the analysis components created and setup for the analysis.

- Mach: Local velocity magnitude non-dimensionalized by the local speed of sound.
- Velocity: Local velocity non-dimensionalized by the freestream speed of sound.
- p/p_{inf} : Pressure non-dimensionalized by the freestream pressure.
- d/d_{inf} : Density non-dimensionalized by the freestream density.
- T/T_{inf} : Temperature non-dimensionalized by the freestream temperature.
- C_p : The coefficient of pressure.
- entropy: The difference of the local entropy and the freestream entropy. Entropy is non-dimensionalized by the ratio of the gas constant to the ratio of the specific heats subtracted by one ($R_{\infty}/[\gamma-1]$).
- enthalpy: The difference of the local total enthalpy and the freestream total enthalpy non-dimensionalized by the square of the speed of sound.
- viscosity (μ): Local molecular viscosity non-dimensionalized by the freestream molecular viscosity .
- eddy μ ratio: Local eddy viscosity non-dimensionalized by the freestream molecular viscosity.
- vorticity: Local vorticity non-dimensionalized by the freestream speed of sound.

- dq: . The L2 norm, $|\mathbf{dq}|$, of the local solution vector.
- dt: The local time step.
- CFL: The local Courant–Friedrichs–Lewy number.
- distance: The distance to the nearest surface in grid units. This value is dimensional.
- MDADI metric: A metric used to determine if the diagonalized ADI or ADI method should be used for a grid line.


The plot menu also allows the user to set the min and max values for the current contour and also show and hide the contour plot key. To remove a min/max constraint, clear the field and leave it blank.

WEDGE



The purpose of this example is to demonstrate the analysis of a simple arbitrary body made up of line segments and the use of multiple overlapping grids. The Reynolds number based on the chord length of 2 is $1.0E7$. Using the y^+ tool, as demonstrated by the NACA 0012 example, indicates that setting the off surface spacing to $2.0E-6$ is reasonable for a y^+ value of 1.


As with the previous examples, start Aero Troll and add an Analysis component. Next, add an airfoil component and name it Wedge. The main window appears as follows.




Problem Specification

Geometry Setup


The next few steps will define the 2D geometry for the wedge. The geometry **MUST** be defined in a clockwise fashion. The geometry definition will start at the trailing edge and loop around to the bottom middle, to the leading edge, to the top middle, and then back to the trailing edge. The wedge is 20% thick and the maximum thickness is located at 50% of the chord. The chord length is 2. To start the process of creating the wedge geometry, open the edit panel for the Wedge component, select the **User Defined** radio button, and set **Start Pt** to $x=2.0$ and $y=0.0$. The start point is the first point of the mold line which describes the geometry and, for this example, the point is the trailing edge.




Next, right click in the **User Defined Mold Line** list to display the segment pop-up menu and select the **Add Segment** menu item.




The segment selection window will appear. Select **Line** and then press the **OK** button.



The line input window will appear.




Set the end point of the line to $x=1.0$ and $y=-.2$. And then select the **OK** button.




Create three additional lines by repeating the process above. Each new line segment should be added below the previous one by right clicking in the region of the **User Defined Mold Line** list below the previously added line segment. The end points for each line are shown in the table below.

x	y
0.0	0.0
1.0	0.2
2.0	0.0


Once the lines have been created, the main window will look as follows.




Because of the geometry of the wedge, an H grid will be used. Unlike a C or an O grid, an H grid will need to know where both the leading and trailing edge are. The trailing edge is automatically set to the location of the start point. However, the leading edge needs to be specified. Right click on the second line segment and select the **Set LE Below** menu item. A warning concerning point distributions will appear. Select the **Yes** button. The leading edge will be positioned at the end point of the second segment.




The edit panel will now look as follows. Notice the yellow leading edge line has moved to a position below the second line segment



The next step is to set the number of surface points for each line segment to 101. Start by right clicking on the first line segment and selecting the **Edit Points** menu item. Unlike the NACA 0012 example, the point distribution will be kept at constant spacing intervals to simplify this example. For a true run, the points should be clustered at the four wedge apexes. This will be left for the user to experiment with separately from this example.




Set the number of points to 101 and select the **OK** button.




In a similar fashion, set the number of points for all the line segments to 101.

Initial CFD Setup


The next step in the process is to add the CFD components and make the required connections. Start the process by creating an AT_Airfoil_CFD component and naming it Wedge CFD. To do this, right on the AT Analysis component and select the AT_Airfoil_CFD component from the **Add** menu. Name the component Wedge CFD.




Next, create a CFD Grid Group for the Wedge CFD component by right clicking on Wedge CFD component and selecting the CFD Grid Group component from the **Add** menu. Set the name of the CFD Grid Group to Wedge Grid Group.




The Wedge Grid Group will define the wedge near body grid. The far field grid will be created using a 2D block grid. Right click on the Wedge CFD component and select the **CFD 2D Block Grid** menu item from the **Add** menu. Name the CFD 2D Block Grid to Wedge Block Grid.




The next step is to link the Wedge CFD method to the wedge. Link the Wedge CFD component to the wedge component by clicking and holding the left mouse button while over the Wedge CFD component and then dragging and dropping the Wedge CFD on to the wedge component.



Now that the Wedge CFD method and wedge are linked, the wedge component can be linked to the Wedge Grid Group. To accomplish this, click and hold the left mouse button while over the wedge component belonging to the Wedge CFD component, and then drag and drop the component on to the Wedge Grid Group component. For this to work, the wedge component under the Wedge CFD component, and not the wedge component under the AT Analysis component, must be used.




Before an analysis is performed, the analysis methodology for the wedge component must be chosen. To select the analysis method for the wedge component, right click on the wedge component node in the components tree to show the component popup menu and then select the Wedge CFD method under the **Analysis Type** submenu.




CFD Gridding

Now that the initial setup is done, a CFD grid must be built for the wedge and the far field. To start this process, open the edit panel for the Wedge Grid Group by right clicking on it and selecting the **Edit** menu item.




The edit panel for the Wedge Grid Group will be displayed.




The first step in the process of defining a grid is to specify the surface grid. For this example, the forward and aft length of the H grid will be kept at 1.0. The forward length is the length of the forward segment which connects to the leading edge. The aft length is the length of the aft segment which connects to the trailing edge. In general, if they are being used, the aft and forward segment length would be modified.

Right click on Aft Segment in surface grid segment list.



The edit window for the segment will appear. Set the number of points to 51 and Beginning Connection to connect and Ending Connection to float. Then select the **OK** button.




The segments which define the geometry are laid out in clockwise fashion so the beginning and end of a segment is representative of that. In the case of the aft segment, one must think of it as being attached to the geometry after the clockwise traverse is made. Therefore the beginning of the aft segment is attached to the end of the last geometry segment. In a similar way, the end of the forward segment is attached to the leading edge.

By setting the aft segment beginning connection to connect, an attempt will be made to smoothly transition the grid spacing from one segment, in this case the trailing edge, to another, in this case the beginning of the aft segment. For the case of aft segment, the trailing edge grid spacing is determined by averaging the grid spacing of the top and bottom surface at the trailing edge.


Next, open the edit dialog for the first line segment. Set the number of points to 51 and both the beginning and ending connections to “Delta % of Avg” and a value of 10%. Then select **OK**. This specifies that the grid spacing at the beginning and end of the

segment is equal to 10% of the average spacing. Therefore, points will be clustered at the beginning and end.




Repeat the process for each of the wedge segments.


For the forward segment, set the number of points to 51, the beginning connection to float, and the ending connection to connect. The grid point spacing settings are the mirror image of the aft segment grid point spacing settings.




The next step is to set the top level parameters for the volume grid. Set the **Beginning Grid B.C.** to Float and set **Xi Volume Smoothing** to 20.



Next right click on the *Geometric(S):[0]* zeta grid segment and select the **Edit Zeta Segment** menu item.



Then set the length to 0.8, the number of points to 151, set the first grid spacing, $ds[0]$, to $1.0E-6$, and select the **OK** button.




The image shows a dialog box titled "Zeta Segment" with a blue title bar and a close button in the top right corner. The dialog contains several input fields and radio buttons. The following fields are circled in red:


- Length:** 0.8
- Number of Nodes:** 151
- Zeta Spacing Type:** Geometric(S)
- ds[0]:** 2.0E-6
- Off Wall Spacing:** 2.0E-6
- Off Wall Ratio:** 1.0707242111657487
- ds[n]:** 0.05284401748139864
- Far Field Spacing:** 0.05284401748139864
- Far Field Ratio:** 1.0707242111657487

At the bottom of the dialog, there are three buttons: **OK**, **Accept**, and **Cancel**. The **OK** button is also circled in red.


Finally, set **Surface B.C.** to Auto and the **Farfield B.C.** to Fringe. A fringe setting indicates to the system that the grid points at that boundary will get their values from another grid, in this case the far field grid.




Next, calculate the grid. Select the **Calculate Grid** menu item from the **Commands** menu.




The main window will look as follows.



Next, set up the Wedge Grid Block. The block grid is a Cartesian grid with constant spacing. Open the edit panel for the Wedge Grid Block by right clicking on it and selecting the **Edit** menu item.




The edit panel for the Wedge Grid Block will be displayed.




The overall procedure is to specify the horizontal (Xi) grid lines and the vertical (Zeta) grid lines. Currently four different spacing types are available: 1) Constant, 2) Geometric(S), 3) Geometric(E), and 4) TanH. Constant grid spacing specifies that the grid cell length is constant along a side. A Geometric(S) grid spacing specifies that the grid cells increase in a geometric fashion and that the user sets the first, i.e. starting, grid cell spacing. A Geometric(E) grid is similar to Geometric(S) except that the user specifies the last, i.e. ending, grid cell spacing. The TanH grid cell spacing is identical to that used for the surface grids and requires the user to specify how the first and last grid cell spacing is to be handled.

For this example, both the horizontal and vertical grid lines will be set as constant. Also, they will be reflected about both horizontally and vertically.


Right click on the Geometric(S):[0] segment in the Xi Grid segment list and select the **Edit Segment** menu item from the popup menu.




The edit panel for the Xi Grid segment will be displayed.




For this example set the length to 3.0, the number of nodes to 61, and the spacing type to constant. Then select the **OK** button.




In a similar fashion, right click on the Geometric(S):[0] segment in the Zeta Grid segment list and select the **Edit Segment** menu item from the popup menu. Set the length to 3.0, the number of nodes to 61, and the spacing type to constant. Then select the **OK** button.




Next, return back to the edit panel for Wedge Grid Block and shift the grid back by two units by setting **X Shift** to 2.0, reflect the grid about the vertical and horizontal axis by selecting the **Reflect YZ** and **Reflect XY** checkboxes, set the **Outer B.C.** to characteristic, and set the **Inner B.C.** to Fringe.



Next, calculate the grid. Select the **Calculate Grid** menu item from the **Commands** menu.



The main window will look as follows.




CFD Run Setup

The next step is to set up the CFD parameters. For this example the Reynolds Averaged Navier Stokes (RANS) solver using the Spalart Allmaras turbulence model will be used. The Left Hand Side (LHS) matrix solver for both the Xi and Zeta direction of the implicit solver will be set to Alternating Direction Implicit (ADI). In general, the ADI method allows for significantly larger Courant-Friedrichs-Lewy (CFL) time step for local time stepping than the Diagonalized Alternating Direction Implicit (DADI) method for grids defining an airfoil. The reason is that the DADI method requires an approximation of the viscous terms in the diagonalized matrix solver. This approximation causes errors in the wake region which reduces the allowed CFL number.


Before a CFD run can be made, Aero Troll will prepare the grids by cutting a hole into the Grid Block grid and connecting the fringe points. In the example the fringe points will be the outer two layers of the wedge grid and the inner two layers at the edge of the hole that will be punched into the block grid. At this time, the hole cutting methodology is very simple; any point which lies within the body or within an area next to the body (buffer zone), specified by the user, is eliminated. The size of the buffer zone is specified with the **Hole Border** parameter. Once the preliminary hole is punched, a number of layers, as specified by the **Trim Passes** parameter, will be stripped away. That new edge

now becomes the edge of the hole. For this example, **Hole Border** will be set to 0.2 and **Trim Passes** will be left at the default of 1. Determining the proper procedure for cutting holes into grids is a trial and error process and is left, to a large degree, to the user. One of the key points is to try to insure that one grid does not pick up boundary layer flow values to the extent possible. The reason is that the gradients within the boundary layer are large and the grid cell sizes of the grids do not match well.


The first step in the CFD process setup is to open the Edit Dialog for the Wedge CFD component by right clicking on the Wedge CFD component in the component tree and selecting the **Edit** menu item. Next, set the solution type to Turb (SA), the number of iterations to 1000, the CFL number to 90, and the LHS Xi and Zeta methods to ADI. These changes are shown below. The CFL number was determined by trail and error. First a value of 60 was used and then increased until the maximum convergence rate was found.




Next, the input screen for the Wedge CFD component will be switched to Grid and the Hold Border parameter will be set to 0.4.




For this example, the Wedge CFD component display variables will be left to the default value. The residual will be extracted every iteration, the CFD load coefficients will be extracted every 20 iterations, and the main window contour plot will be extracted every 100 iterations. If the user chooses, changes to these values can be done in the Display input screen for the Wedge CFD component.




The next step is to build the overlapping grid set by selecting the **Calculate Grids** menu item from the **Commands** menu.




The main window will look as follows.




Various characteristics of the wedge and block can be investigated by selecting menu items from the **Points** sub menu under the **View** menu of either the Wedge Grid Group or the Wedge Grid Block components. For example, the fringe points for the wedge grid can be displayed by selecting the **Show Fringe** menu item of the **Points** menu under the **View** menu.



The main window appears as follows.




In a similar fashion, the fringe points for the block grid can also be displayed. The image below shows the fringe points for both the wedge and block grids. The view was zoomed into the wedge to see the block grid fringe points clearer.




To return back to this example, hide the fringe point display and zoom out from the view.

Before the CFD run can be executed, the freestream values must be set. Right click on the AT Analysis component and select the **Edit** menu item.




The edit panel for the AT Analysis component will be displayed. Set the included angle of attack to 4.0, the Mach number to 2.0, and the Reynolds number per length to 5E6. The Reynolds number for the wedge based on the chord is 10E6. Therefore, since the chord is 2.0, the Reynolds number per length is $\frac{1}{2}$ the root chord Reynolds number. Finally, sRef and lRef are set to 2.0.




CFD Execution


To execute the run, select the **Execute** menu item from the AT Analysis component menu.




Once execution begins, the Exec AT CFD Dialog will be shown. To allow for cleaner residual plots, some of the settings will need to be changed. For the Wedge Grid Group deselect the **CFL rMax**, **sAvg**, and **sMax** check boxes. All that will remain checked is **CFL rAvg**. This indicates that only the average CFL residual will be displayed.




Next, go to the Wedge Grid Block Grid Group and deselect the **Include in Global Block** check box. This indicates that the Wedge Grid Block residual values will not be included in the plot when the **Plot All** button is selected.




After a few iterations, select the **Plot All** button of the Wedge Grid Group Grid Group.




The residual plot will be shown below.




After a few more iterations the **For+Mom** tab of the Exec AT CFD Dialog is selected and the **Plot All** button is selected.




The plot for CZ is shown below. The plot contains the curves for both the wedge and the block. The CZ for the block is zero.




Once the CFD job is complete, dismiss the Exec AT CFD Dialog by selecting the **Close** button.




To view the results after the CFD run is completed, select the **Results** menu item under the AT Analysis and Wedge components. The AT Analysis results will provide the results for the complete configuration and the Wedge results will provide more detail, such as surface pressure and skin friction coefficients. To view the results for the Wedge, right click on the wedge and select the **Results** menu item.



The results window will be displayed. Select the **Plot** button to display the wedge cp.




The cp plot will be displayed.



This concludes the example.


MULTI-ELEMENT Airfoil



The purpose of this example is to demonstrate the analysis of a more complex geometry which involves multiple geometry elements. Hopefully this example will guide the way in creating other arbitrary 2D geometries.


Problem Specification

As with the previous examples, start Aero Troll and add an Analysis component. Next, add three airfoil components and name them Slat, Main, and Flap. The main window appears as follows.




Slat Geometry


To start the process of creating the slat geometry, open the edit panel for the Slat component, select the **User Defined** radio button, and set **Start Pt** to $x=0.413864$ and $y=0.11262594$. The start point is equal to the first point of the cubic spline which will be read in later.




Next, right click in the **User Defined Mold Line** list to display the segment pop-up menu and select the **Add Segment** menu item.




The segment selection window will appear. Select **Cubic Spline** and then press the **OK** button.



The cubic spline input window will appear.



Right click on an input field for the cubic spline input table to display the cubic spline pop-up menu, select the **Open** menu item, and open the 30P-30NCoord_slat_A.dat file which can be found in the MD_30P_30N example folder.



The window will appear as follows.

Update Object

Start Slope: Input Connect Float

dx dy


End Slope: Input Connect Float

dx dy

X	Y
0.41386400	0.11262594
0.36707678	0.06958377
0.27355146	-0.01649761
0.17999608	-0.10257094
0.08647075	-0.18865232
-0.05176790	-0.32145596
-0.18422850	-0.46004347
-0.31057911	-0.60419779
-0.43035068	-0.75385135
-0.54290189	-0.90901493
-0.64726890	-1.06981796
-0.74203199	-1.23643148
-0.80918941	-1.37328741
-0.86132211	-1.49788693
-0.92016969	-1.68024393
-0.95456492	-1.86865365
-0.95136671	-2.05987310
-0.88852444	-2.23964712
-0.73080485	-2.35996946
-0.63147374	-2.37537599
-0.58171800	-2.36717545


OK Cancel

Select the **OK** button to accept the input. Next, right click in the **User Defined Mold Line** list below the previously added cubic spline segment and add a new cubic spline. For this example, the new cubic spline *must* be added below the previously added cubic spline.




Then insert the 30P-30NCoord_slat_B.dat file into the new cubic spline following the same process outlined above.


The main window now appears as follows. The coarse outline of the slat will be modified later.




The next step is to add an elliptical arc segment between the end of the first cubic spline and the beginning of the second cubic spline. To do this, right click on the second cubic spline segment and select the **Add Segment** menu item. This will add a segment in the position selected and push down the segment which occupies the slot.




Select an Elliptical Arc and then select the **OK** button.



When the elliptical arc edit window appears set the End Pt. to $x=-0.575833$ $y=-2.37736857$ and set both the Start and End slope to Connect. Then select the **OK** button.



Next, set the number of points for the first cubic spline to 101 by right clicking on the first cubic spline and selecting the **Edit Points** menu item.




Set the number of points to 101 and select the **OK** button.

The image shows a dialog box titled "Update Object" with a close button in the top right corner. The dialog contains several input fields and radio buttons. The "# of Points" field is circled in red and contains the value "101". The "OK" button at the bottom left is also circled in red. Other fields include "Total Length" (3.1950025030348517), "Average ds" (0.7987506257587129), "Beginning Connection" (Float selected), "Delta S" (0.7987506257587129), "Delta %" (25.0), "Delta % of Avg" (100.0), "Connect" (unselected), and "Fixed" (checked). The "Ending Connection" section has identical settings.

Total Length	3.1950025030348517
Average ds	0.7987506257587129
# of Points	101
Beginning Connection	
Float	<input checked="" type="radio"/>
Delta S	<input type="radio"/> 0.7987506257587129
Delta %	<input type="radio"/> 25.0
Delta % of Avg	<input type="radio"/> 100.0
Connect	<input type="radio"/>
Fixed	<input checked="" type="checkbox"/>
Ending Connection	
Float	<input checked="" type="radio"/>
Delta S	<input type="radio"/> 0.7987506257587129
Delta %	<input type="radio"/> 25.0
Delta % of Avg	<input type="radio"/> 100.0
Connect	<input type="radio"/>
Fixed	<input checked="" type="checkbox"/>


Buttons: **OK** (circled), Cancel, Accept, Revert

In a similar fashion, set the number of points on the elliptical arc to 11 and the number of points on the second cubic spline to 101. The main window will look similar to the following image.




Main Geometry


To start the process of creating the main geometry, open the edit panel for the Main component, select the **User Defined** radio button, and set **Start Pt** to $x=19.2256548$ $y=0.6740228$.




Next, right click on the **User Defined Mold Line** list to display the segment pop-up menu and select the **Add Segment** menu item.




The segment selection window will appear. Select the **Cubic Spline** and then press the **OK** button.





Right click on an input field for the cubic spline input table to display the cubic spline pop-up menu, select the **Open** menu item, and open the 30P-30NCoord_main_A.dat file.




The window will appear as follows.



Select the **OK** button to accept the input. Next, right click in the **User Defined Mold Line** list below the previously added cubic spline segment and add a line segment. For this example, the line segment *must* be added below the previously added cubic spline.




Set the line end point to $x=15.4$, $y=-0.378928$, then select the **OK** button to accept the input. Next, right click in the **User Defined Mold Line** list below the previously added line segment and add a new cubic spline. For this example, the new cubic spline *must* be added below the line segment.




Then insert the 30P-30NCoord_main_B.dat file into the new cubic spline following the same process outlined above for the first cubic spline.

The main window will now look as follows.




For the main airfoil body, set the number of points of the first cubic spline to 21 points and set the number of points on the line to 21 points.


The next step is to split the last cubic spline by adding a break at the leading edge. To create the break, the surface length from the beginning of the cubic spline to the leading edge must be determined. First select the **Mold Line** menu item from the **Plot** menu of the main airfoil component edit panel.




The segment display for the main airfoil will appear. Select the **Show Cntrl Pts** menu item of the Segment Display's **View** menu.



Then zoom into the leading edge by using the middle mouse button to zoom and the left mouse button to translate right/left and up/down. The Segment Display window will look similar to the figure below.




Double click on the control point at the leading edge. The point to click on is shown below. A Point Display window containing the information for that point will appear.




The Point Display window contains the x, y, and z coordinates for the control point. The window also contains the distance along the surface from the beginning of the segment to the control point. This distance is approximately 14.695. It should be noted that the Point Display window will only appear when a control point is double clicked. Double clicking anywhere else on the segment will not display information about the clicked location. Next, close the Point Display and Segment Display windows by selecting the X in the upper right hand corner of the window frame for both windows.


The next step is to create a break at the leading edge. Right click on the second cubic spline in the Main airfoil edit panel and select the **Add Break** menu item.




The add break window will appear. Set the number of points to 101, the segment length to 14.695, and then select the **OK** button.



Next, right click on the last segment of the second cubic spline, Cubic Spline[1], and select the **Edit Points** menu item. Then set the number of points to 101 and select the **OK** button.




The main window will appear as follows.




Flap Geometry


To start the process of creating the flap geometry, open the edit panel for the Flap component, select the **User Defined** radio button, and set **Start Pt** to $x=24.81195666$, $y=-3.21197394$.




Next, right click on the **User Defined Mold Line** list to display the segment pop-up menu and select the **Add Segment** menu item.




The segment selection window will appear. Select the **Cubic Spline** and then press the **OK** button.




The cubic spline input window will appear.



Right click on the cubic spline input table to display the cubic spline pop-up menu, select the **Open** menu item, and open the 30P-30NCoord_flap.dat file.




The window will appear as follows.




Next, find the leading edge surface distance for the flap using the same method as outlined in the main airfoil section. For the flap, the surface distance to the leading edge is 6.8576. Then, as with the main airfoil, create a break at this location and set the number of points for both the top and bottom segment to 101.

The main window will look as follows.




Initial CFD Setup


The next step in the process is to add the CFD components and make the required connections. The process is similar to that described for the NACA 0012 and Wedge example. Start the process by creating an AT_Airfoil_CFD component and naming it MD_30P_30N. Next, create three CFD Grid Groups for the MD_30P_30N and name them Slat Grid Group, Main Grid Group, and Flap Grid Group. Next, add two CFD 2D Grid Block components to the MD_30P_30N. Name the first one Near Block Grid and the second one Far Block Grid. The main window should look like the following figure.



The next step is to link the MD_30P_30N method to the slat, main, and flap elements of the multi-element airfoil. Link the MD_30P_30N component to the slat component by clicking and holding the left mouse button while over the MD_30P_30N component and then dragging and dropping the MD_30P_30N on to the slat component. Repeat the process for the main and flap elements. The main window should look like the following figure.



Now that the MD_30P_30N method and elements are linked, the element components can be linked to the grid groups. To accomplish this, click and hold the left mouse button while over an element component, which is attached to the MD_30P_30N component, and then drag and drop the component on to the grid group component. For this to work, the element component under the MD_30P_30N component, and not the element component under the AT Analysis component, must be clicked on. The main window should look like the following figure.



Before an analysis is performed, the analysis methodology for the element components must be chosen. To select the analysis method for the element components, right click on an element component node in the components tree to show the component popup menu and then select the MD_30P_30N method under the **Analysis Type** submenu.

CFD Gridding


Now that the geometry setup is completed, CFD grids must be built for the slat, main, and flap elements.


The process for setting the Main Grid Group parameters will be demonstrated first. The Main Grid Group core parameters requiring changes are shown below.

Main Grid Group Core Parameters

Grid Type:	C grid
Aft length:	13
Beginning Grid B.C.:	Float
End Grid B.C.:	Float
Xi Volume Smoothing:	10.0
Xi Slope Smoothing:	10.0
Zeta Spread End:	300.0
Avg. Volume Weighting	0.6
Surface B.C.:	Auto
Farfield B.C.:	Fringe

Open the edit panel for the Main Grid Group and make the changes shown above. The following two figures identify the fields which need to be changed.







Next, create a break in the second cubic spline segment at the position shown below, and set the number of points to 76.

Main Grid Group Segment Breaks

Second “Main::Cubic Spline” Segment



# of Points	76
S	14.695



Next, modify the zeta grid segment using the following values.

Main Grid Group Zeta Grid Parameters

Length: 2.2
Number of nodes: 76
Zeta Spacing Type: Geometric(S)
ds[0]: 5.0E-5




Next, modify the surface grid segments.

Main Grid Group Segment Parameters

Aft Segment	
# of Points:	31
Beginning Connection:	Connect
Ending Connection:	Float
Cubic Spline Segment	
# of Points:	21
Beginning Connection:	Delta S=0.02
Ending Connection:	Connect
Line Segment	
# of Points:	6
Beginning Connection:	Float
Ending Connection:	Float
Cubic Spline[0] Segment	
# of Points:	76
Beginning Connection:	Connect
Ending Connection:	Delta S=0.005
Cubic Spline[1] Segment	
# of Points:	101
Beginning Connection:	Connect
Ending Connection:	Delta S=0.02
Base Segment	
# of Points:	11
Beginning Connection:	Delta S=5.0E-5
Ending Connection:	Delta S=5.0E-5

Start with the Aft Segment.



The following figure shows the input window for the Aft Segment.

Segment

Total Length: 13.0

Average ds: 3.25

of Points: 31

Beginning Connection

Float:

Delta S: 3.25

Delta %: 25.0

Delta % of Avg: 100.0

Connect: Fixed

Ending Connection

Float:

Delta S: 3.25

Delta %: 25.0

Delta % of Avg: 100.0

Connect: Fixed

OK Cancel Accept Revert

The following figure shows the input window for Main::Cubic Spline.

Segment

Total Length: 3.8275637856287155

Average ds: 0.9568909464071789

of Points: 21

Beginning Connection

Float:

Delta S: 0.02

Delta %: 25.0

Delta % of Avg: 100.0

Connect: Fixed

Ending Connection

Float:

Delta S: 0.9568909464071789


Delta %: 25.0

Delta % of Avg: 100.0


Connect: Fixed

OK Cancel Accept Revert

The following figure shows the input window for *Main::Line*.



The following figure shows the input window for *Main::Cubic Spline[0]*.




The following figure shows the input window for *Main::Cubic Spline[1]*.

Total Length	18.851655751914233
Average ds	4.712913937978558
# of Points	101
Beginning Connection	
Float	<input type="radio"/>
Delta S	<input type="radio"/> 0.005
Delta %	<input type="radio"/> 0.02652286921530641
Delta % of Avg	<input type="radio"/> 0.10609147686122564
Connect	<input checked="" type="radio"/> Fixed
Ending Connection	
Float	<input type="radio"/>
Delta S	<input checked="" type="radio"/> 0.02
Delta %	<input type="radio"/> 122.85091903648929
Delta % of Avg	<input type="radio"/> 491.40367614595715
Connect	<input checked="" type="radio"/> Fixed


The following figure shows the input window for *Main::Top Base*.

Total Length	0.008152035210914416
Average ds	0.002038008802728604
# of Points	11
Beginning Connection	
Float	<input type="radio"/>
Delta S	<input checked="" type="radio"/> 5.0E-5
Delta %	<input type="radio"/> 25.0
Delta % of Avg	<input type="radio"/> 100.0
Connect	<input checked="" type="radio"/> Fixed
Ending Connection	
Float	<input type="radio"/>
Delta S	<input checked="" type="radio"/> 5.0E-5
Delta %	<input type="radio"/> 25.0
Delta % of Avg	<input type="radio"/> 100.0
Connect	<input checked="" type="radio"/> Fixed

Next, calculate the grid.



The grid is shown in the following image of the main window.



The next step is to set up the Slat Grid Group. The process is very similar to the set up of the Main Grid Group. Only the parameters which require changing are shown below. Note that the field entries Sub Steps and Avg. Vol. Weighting for the Slat Grid Group Core Parameters are different than the Main Grid Group.

Slat Grid Group Core Parameters

Grid Type:	C grid
Aft length:	2.0
Beginning Grid B.C.:	Float
End Grid B.C.:	Float
Sub Steps:	4
Xi Volume Smoothing:	10.0
Xi Slope Smoothing:	0.0
Zeta Spread End:	300.0
Surface B.C.:	Auto
Farfield B.C.:	Fringe


Slat Grid Group Zeta Grid Parameters:

Length:	2.2
Number of nodes:	76
Zeta Spacing Type:	Geometric(S)
ds[0]:	5.0E-5

Slat Grid Group Segment Parameters

Aft Segment	
# of Points:	26
Beginning Connection:	Connect
Ending Connection:	Float
Cubic Spline Segment	
# of Points:	51
Beginning Connection	Delta S=0.003
Ending Connection	Connect
Elliptic Segment	
# of Points:	11
Beginning Connection	Float
Ending Connection	Float
Cubic Spline Segment	
# of Points:	76
Beginning Connection	Connect
Ending Connection	Delta S=0.003
Base Segment	
# of Points:	11
Beginning Connection	Delta S=5.0E-5
Ending Connection	Delta S=5.0E-5

After setting the parameters for the Slat Grid Group, calculate the grid. The grid is shown in the following image of the main window.



Next, set up the Flap Grid Group.

Flap Grid Group Core Parameters

Grid Type:	C grid
Aft length:	8
Beginning Grid B.C.:	Float
End Grid B.C.:	Float
Sub Steps:	1
Xi Volume Smoothing:	10.0
Xi Slope Smoothing:	0.0
Zeta Spread End:	300.0
Surface B.C.:	Auto
Farfield B.C.:	Fringe

Flap Grid Group Segment Breaks

Flap::Cubic Spline	
# of Points	76
S	6.8576

Flap Grid Group Zeta Grid Parameters

Length:	2.2
Number of nodes:	76
Zeta Spacing Type:	Geometric(S)
ds[0]:	5.0E-5

Flap Grid Group Segment Parameters

Aft Segment

# of Points:	21
Beginning Connection:	Connect
Ending Connection:	Float

Cubic Spline[0] Segment

# of Points:	76
Beginning Connection:	Delta S=0.006
Ending Connection:	Delta S=0.006


Cubic Spline[1] Segment

# of Points:	76
Beginning Connection:	Delta S=0.006
Ending Connection:	Delta S=0.006

Base Segment

# of Points:	21
Beginning Connection:	Delta S=5.0E-5
Ending Connection:	Delta S=5.0E-5

After setting the parameters for the Flap Grid Group, calculate the grid. The grid is shown in the following image of the main window.




Next, set up the Near Block Grid. The setup is similar to that of the Wedge example. The Near Block Grid is comprised of two grid zones, an inner zone and an outer zone.


The following changes need to be made to the Near Block Grid and they are outlined in the screen capture that follows.

Near Block Grid Core Parameters


X Shift	13.0
Z Shift	-1.0
Reflect YZ Plane	true
Reflect XY Plane	true
Outer B.C.	Fringe
Inner B.C.	Fringe



The next step is to create a grid segment for both the Xi and Zeta grid edges. To do this, right click on the Geometric(S):[0] segment in the Xi Grid list and select the **Add Segment** menu item. This is shown below.



Edit the first Xi Grid segment by right clicking on Geometric(S):[0] segment and selecting the **Edit Segment** menu item.




The edit window for the segment will appear. Make the following changes.

Xi Grid Segment Parameters

First Segment

Length:	17.0
Number of Nodes:	44
Z Spacing Type:	Constant




Next, edit the second Xi Grid Segment and make the following changes.

Xi Grid Segment Parameters

Second Segment

Length:	30.0
Number of Nodes:	26
Z Spacing Type:	Geometric(S)
ds[0]:	Connect



Next, add a second segment to the Zeta Grid list and make the following changes.

Zeta Grid Segment Parameters


First Segment

Length:	4.0
Number of Nodes:	11
Z Spacing Type:	Constant


Second Segment

Length:	30.0
Number of Nodes:	26
Z Spacing Type:	Geometric(S)
ds[0]:	Connect

Next, calculate the grid.



The main window will appear as follows.




Next, set up the Far Block Grid. The setup is similar to that of the Near Block Grid. The Far Block Grid is comprised of two grid zones, an inner zone and an outer zone. Unlike the Near Block Grid, the inner zone for the Far Block Grid will be deactivated to make a hole for the Near Block Grid.


The following changes need to be made to the Far Block Grid and they are outlined in the screen capture that follows.

Far Block Grid Core Parameters


X Shift	13.0
Z Shift	-1.0
Reflect YZ Plane	true
Reflect XY Plane	true
Outer B.C.	Characteristic
Inner B.C.	Fringe



The next step is to create a grid segment for both the Xi and Zeta grid edges. To do this, right click on the Geometric(S):[0] segment in the Xi Grid list and select the **Add Segment** menu item. This is shown below.



Edit the first Xi Grid segment by right clicking on Geometric(S):[0] segment and selecting the **Edit Segment** menu item.




The edit window for the segment will appear. Make the following changes.

Xi Grid Segment Parameters

First Segment

Length:	42.0
Number of Nodes:	22
Z Spacing Type:	Constant




Next, edit the second Xi Grid Segment and make the following changes.

Xi Grid Segment Parameters

Second Segment

Length:	2000.0
Number of Nodes:	31
Z Spacing Type:	Geometric(S)
ds[0]:	Connect



Next, add a second segment to the Zeta Grid list and make the following changes.

Zeta Grid Segment Parameters


First Segment

Length:	30.0
Number of Nodes:	16
Z Spacing Type:	Constant


Second Segment

Length:	2000.0
Number of Nodes:	31
Z Spacing Type:	Geometric(S)
ds[0]:	Connect


Next, deactivate the inner zone by right clicking on the Constant Xi and Zeta segments and selecting the **Deactivate** menu item.



Next, calculate the grid.



The main window will appear as follows.




CFD Run Setup


The next step is to make changes to the MD_30P_30N component. The following changes will be made.

MD_30P_30N

Solution Type:	Turb (SA)
Iterations:	2500
Time Stepping:	CFL
CFL:	60
LHS xi:	ADI
LHS zeta:	ADI




Next cut the grid holes and link the grid together by selecting **Calculate Grids** menu item under the **Commands** menu. Note that if the grids were not previously calculated under the various Grid Groups, the grids would be calculated at this time. Then use the mouse to zoom closer to the multi element airfoil. The main window should appear somewhat close to the following image.



The final step before running the CFD analysis is to modify the AT Analysis component. The Reynolds number for this example is $9e6$ based on the non extended (slat and flaps not deployed) chord length of 22. Therefore, the Reynolds number per length is $9e6$ divided by 22 which equals 409090.9.


AT Analysis

AlphaC	8.1
Mach	0.2
Re per len	409090.9
sRef	22.0
lRef	22.0
xMom	5.5




CFD Execution

Under the AT Analysis menu, select the **Execute** menu item.





The next series of steps will reduce the number of residuals which are plotted. The objective is to plot only the maximum solution change for the slat, main, and flap element. The residuals for the near and far block will be disabled to make the residual display for this example simple. However, in general, a residual should be included for each grid to ensure that they all converge.

To modify the slat residual, select the Slat Grid Group from the Grid Group drop down menu in the Exec AT CFD Dialog. Then deselect the **CFL rAvg**, **CFL rMax**, and **sMax** check boxes.





Repeat the process for the Main Grid Group and the Flap Grid Group.






For the near and far blocks, deselect the **Include in Global Plot** check box. Deselecting this check box will specify that the residuals should not be included in the residual plot when the **Plot All** button is selected.






Finally, to plot the residuals, return to the slat grid group and select **Plot All** button.



The residual plot will be shown.



After the 2500 iterations are complete, the results are as follows.

Total Results			
	Total	Pressure	Friction
CX	-3.91199E-01	-4.01123E-01	9.92490E-03
CY	0.00000E+00	0.00000E+00	0.00000E+00
CZ	3.17961E+00	3.17757E+00	2.03897E-03
Cl	0.00000E+00	0.00000E+00	0.00000E+00
Cm	-5.98276E-01	-5.99620E-01	1.34428E-03
Cn	0.00000E+00	0.00000E+00	0.00000E+00
CD	6.07147E-02	5.06015E-02	1.01132E-02
CL	3.20301E+00	3.20239E+00	6.20199E-04

	Slat		
	Total	Pressure	Friction
CX	-2.24704E-01	-2.25736E-01	1.03239E-03
CY	0.00000E+00	0.00000E+00	0.00000E+00
CZ	2.51505E-01	2.50403E-01	1.10182E-03
Cl	0.00000E+00	0.00000E+00	0.00000E+00
Cm	8.44135E-02	8.41257E-02	2.87767E-04
Cn	0.00000E+00	0.00000E+00	0.00000E+00
CD	-1.87025E-01	-1.88202E-01	1.17734E-03
CL	2.80657E-01	2.79711E-01	9.45366E-04

	Main		
	Total	Pressure	Friction
CX	-3.87818E-01	-3.94743E-01	6.92523E-03
CY	0.00000E+00	0.00000E+00	0.00000E+00
CZ	2.42860E+00	2.42708E+00	1.51560E-03
Cl	0.00000E+00	0.00000E+00	0.00000E+00
Cm	-3.18482E-01	-3.19109E-01	6.27026E-04
Cn	0.00000E+00	0.00000E+00	0.00000E+00
CD	-4.17563E-02	-4.88260E-02	7.06969E-03
CL	2.45901E+00	2.45849E+00	5.24703E-04

	Flap		
	Total	Pressure	Friction
CX	2.21323E-01	2.19356E-01	1.96728E-03
CY	0.00000E+00	0.00000E+00	0.00000E+00
CZ	4.99505E-01	5.00084E-01	-5.78449E-04
Cl	0.00000E+00	0.00000E+00	0.00000E+00
Cm	-3.64207E-01	-3.64637E-01	4.29489E-04
Cn	0.00000E+00	0.00000E+00	0.00000E+00
CD	2.89496E-01	2.87630E-01	1.86615E-03
CL	4.63337E-01	4.64187E-01	-8.49870E-04

COMPONENTS

This section describes the following components and interfaces which have been added since the last release of Aero Troll.

- 1) Nose
- 2) Notes
- 3) Airfoil
- 4) AT_Airfoil_CFD
- 5) CFD Grid Group (Airfoil)
- 6) CFD Block Grid
- 7) Exec AT CFD Dialog

Nose

The screenshot shows the 'Edit Window' dialog for the 'Nose' component. The window title is 'Edit Window'. The 'Nose' component is selected, and the 'Commands' tab is active. The 'Settings' section contains the following parameters:

Parameter	Value
X Shift	0.0
Y Shift	0.0
Z Shift	0.0
Psi Rot	0.0
Tht Rot	0.0
Phi Rot	0.0
Include Wake	<input checked="" type="checkbox"/>
Local Wake	<input type="checkbox"/>
Nose Type	<input checked="" type="radio"/> Cone <input type="radio"/> Ogive
Blunt Radius	0.0
Nose Radius	0.5
Nose Length	2.0
Tip Radius	0.0
Nose Droop	0.0
Tip Panels	4
Nose Panels	10
Base Panels	4
Inc. Base Load	<input checked="" type="checkbox"/>
Seg: 1	
Theta	180.0
Include Body	<input checked="" type="checkbox"/>
Theta Panels	12

Buttons at the bottom: Accept, Accept All, Revert, Revert All.

The Nose component is a circular geometry which has either a cone or ogive nose.

After executing the analysis method for this component, the final integrated loads and moments are shown in the results panel of the base component. However, the load distribution for the Nose is presented in the results panel for the Nose component.

The Nose component has the following parameters.

- X Shift*: The amount that this component's coordinate system is shifted backward from the parent coordinate system. The value is measured along the parent coordinate system x axis.

Y Shift: The amount that this component's coordinate system is shifted starboard from the parent coordinate system. The value is measured along the parent coordinate system y axis.

Z Shift: The amount that this component's coordinate system is shifted upward from the parent coordinate system. The value is measured along the parent coordinate system z axis.

Psi Rot: The amount, in degrees, that this component's coordinate system is yawed. The rotation transformations are applied in the same order as the aircraft Euler angle system, i.e. yaw, pitch, and then roll, and are with respect to the parent coordinate system.

Tht Rot: The amount, in degrees, that this component's coordinate system is pitched. The rotation transformations are applied in the same order as the aircraft Euler angle system, i.e. yaw, pitch, and then roll, and are with respect to the parent coordinate system.

Phi Rot: The amount, in degrees, that this component's coordinate system is rolled. The rotation transformations are applied in the same order as the aircraft Euler angle system, i.e. yaw, pitch, and then roll, and are with respect to the parent coordinate system.

Include Wake: If selected, wake panels will be included in the PANAIR calculation.

Local Wake: If selected, the wake will follow along the x axis of the parent coordinate system otherwise the wake will follow along the x axis of the global coordinate system.

Nose Type: A radio button grouping for selecting either a **Cone** or **Ogive** nose.

Blunt Radius: The radius of the flat forward section if the nose tip has a flat forward section. The value must be greater than or equal to zero. If the value is equal then the nose does not have a flat forward directed tip surface.

Nose Radius: The maximum radius of the nose.

Nose Length: The length of the nose. Measured parallel to the local x axis from the nose tip to the shoulder. This value must be greater than zero.

Tip Radius: The nose tip radius. The value must be greater than or equal to zero.

Nose Droop: The droop of the nose. Measured parallel to the local z axis.

Tip Panels: The number of panels laid out along the nose tip center line from the forward point of the nose tip to the junction of the nose tip and nose. The value must be greater than zero.

Nose Panels: The number of panels laid out in the axial direction from the junction of the nose tip to the shoulder. The value must be greater than zero.

Base Panels: The number of panels on the base along the radius. The value must be greater than or equal to zero. If the value is zero then a base will not be included.

Inc. Base Load: If selected the base will not be used in the calculation of the aerodynamic loads.


The following input parameters are for a nose segment. Each nose segment represents a set of panels laid out along a portion of the circumference. The segments are then connected side edge to side edge to loop over the circumference of the nose. The total number of panels along the circumference of the body is the sum of the number of panels in each segment. Each segment will be represented by a panel network for a PANAIR analysis.

Theta: The ending circumferential theta location for the segment. The segment will start at the ending theta of the previous segment. For the first segment, the starting theta is the ending theta of the last segment. The ending theta location must not match the ending theta location of any other segment. A theta value of zero represents the top of the body. The theta value is positive in a clockwise direction when viewed from the back towards the front. The value is in degrees.

Include Body: If unselected panels will not be laid out along the circumference.


Theta Panels: The number of panels in the theta direction for this segment. The value must be greater than zero.

Notes



The notes component allows the user to type notes into the edit panel for the notes component and save the notes when the Aero Troll case is saved.

Airfoil



The Airfoil component allows for the specification of a NACA airfoil or a user defined 2D shape. Both methods will be briefly introduced before the Airfoil component fields are described.

NACA Airfoil Description

The types of NACA airfoils which can be specified are four-digit, modified four-digit, five-digit, modified five-digit, 1-series, 6-series, and 6A-series. Each is discussed below. The underlined characters in *italic* are characters which need to be replaced by a numeric value.

Four-Digit

The format for the four-digit airfoil is *mptt*:

- m*) The maximum value of the camber in per cent of the chord.
- p*) The distance from the leading edge to the location of the maximum camber in tenths of the chord.
- tt*) The section thickness in per cent of the chord.

Examples are:

0006
0012
4415

Modified Four-Digit

The format for the modified four-digit airfoil is *mptt-lq*:

- m*) The maximum value of the camber in per cent of the chord.
- p*) The distance from the leading edge to the location of the maximum camber in tenths of the chord.
- tt*) The section thickness in per cent of the chord.
- l*) A leading edge value indicator.
- q*) The position of maximum thickness in tenths of the chord.

Examples are:

0012-64

0012-06

Five-Digit

The format for the five-digit airfoil is *ccctt*:

- ccc*) The possible values are 210, 220, 230, 240, 250, 221, 231, 241, and 251.
- tt*) The section thickness in per cent of the chord.

Examples are:

21010

23012

25101

Modified Five-Digit

The format for the modified five-digit airfoil is *ccctt-lq*:

- ccc*) The possible values are 210, 220, 230, 240, 250, 221, 231, 241, and 251.
- tt*) The section thickness in per cent of the chord.
- l*) The leading edge value indicator.
- q*) The position of maximum thickness in tenths of the chord.

Examples are:

23012-64

23012-06

1-Series

The format for the 1-series airfoil is 16-00*tt*. Currently, only non-chamber 1 series can be handled by Aero Troll.

- tt*) The section thickness in per cent of the chord.

An example is:

16-0012

6-Series

The format for the 6-series airfoil is 6*p-dtt a=a*. The last part, *a=a*, is optional. If it is not included then 'a' is assumed to be 1.0. In general, the 6 series designation includes the range of lift coefficient in tenths above and below the design lift coefficient in which favorable pressure gradients exist on both surfaces as a subscript. For example, the 3 in the designation 65₃-218 would be the range indicator. This indicator does not modify the geometry and therefore is not

included in the designation for Aero Troll. The 6-series airfoils used by Aero Troll are the newer 6-series airfoils. The older series are designated with a non subscript range indicator, i.e. 65,3-218. The older series are included in Aero Troll.

- p)* The chordwise position of minimum pressure in tenths of the chord behind the leading edge for the basic symmetrical section at zero lift. The value can range from 3 to 7.
- d)* The design lift coefficient in tenths.
- tt)* The section thickness in per cent of the chord.
- a)* The mean line designation.

Examples are:

63-012

65-618 a=0.5

67-012

6A-Series

The format for the 6-series airfoil is 6pAdtt.

- p)* The chordwise position of minimum pressure in tenths of the chord behind the leading edge for the basic symmetrical section at zero lift. The value can range from 3 to 7.
- d)* The design lift coefficient in tenths.
- tt)* The section thickness in per cent of the chord.

An example is:

63A012

User Defined 2D Shape

The Airfoil Component also allows the user to define an arbitrary 2D geometry by means of linking together a series of segments.

Five types of segments are available

- 1) Line
- 2) Circular Arc
- 3) Elliptical Arc
- 4) B-Spline
- 5) Cubic Spline

Menu Items


The Airfoil edit Panel has three menus: Commands, View, and Plot. Each will be described in turn.

Commands

Export Surface Pts...

Export Surface Pts: The **Export Surface Pts** menu item allows the user to export the airfoil or 2D geometry surface points to a file.


View



Show/Hide Pts: Selecting the **Show Pts** menu item will display the surface points. If the surface points are already shown then the **Hide Pts** menu item will be displayed in place of the **Show Pts** menu item.

Show/Hide Cntrl Pts: Selecting the **Show Cntrl Pts** menu item will display the control points of the segments used to build 2D geometries. An airfoil does not have control points. If the control points are already visible, then the **Hide Pts** menu item will be displayed in place of the **Show Cntrl Pts** menu item.

Plot



Mold Line: The **Mold Line** menu item displays the mold line for a 2D geometry in a separate window. The **Mold Line** menu item is disabled for the airfoil geometry.

Component Fields

The Airfoil component has three input sections: the main input section, the NACA input section, and the 2D geometry input section.

Main Input Section

The Airfoil component's main input section has the following parameters.

X Shift: The amount that this component's coordinate system is shifted backward from the parent coordinate system. The value is measured along the parent coordinate system x axis.

Y Shift: The amount that this component's coordinate system is shifted starboard from the parent coordinate system. The value is measured along the parent coordinate system y axis.

Z Shift: The amount that this component's coordinate system is shifted upward from the parent coordinate system. The value is measured along the parent coordinate system z axis.

Psi Rot: The amount, in degrees, that this component's coordinate system is yawed. The rotation transformations are applied in the same order as the aircraft Euler angle system, i.e. yaw, pitch, and then roll, and are with respect to the parent coordinate system.

Tht Rot: The amount, in degrees, that this component's coordinate system is pitched. The rotation transformations are applied in the same order as the aircraft Euler angle system, i.e. yaw, pitch, and then roll, and are with respect to the parent coordinate system.

Phi Rot: The amount, in degrees, that this component's coordinate system is rolled. The rotation transformations are applied in the same order as the aircraft Euler angle system, i.e. yaw, pitch, and then roll, and are with respect to the parent coordinate system.

Chord: The chord length of the airfoil or 2D geometry. For an airfoil, this is the distance between the leading and trailing edge. For a 2D geometry this is the distance between the starting point and a point specified as the leading edge. If the chord length is set to a number less than or equal to 0.0, then the airfoil or 2D geometry will not be scaled. The default length of an airfoil is 1.0 unit long.

Category: If the **NACA** radio button is selected then the user must supply a definition for a NACA airfoil. If the **User Defined** radio button is selected then the user creates a 2D geometry by means of segments.

NACA Input Section

NACA Airfoil:	67-012		
Sharpen TE:	<input checked="" type="checkbox"/>		
# of Camber Line Pts:	101		
	L.E.		T.E.
Float	<input checked="" type="radio"/>		<input type="radio"/>
Delta %	<input type="radio"/>	1.0	<input type="radio"/>
Delta % of Avg	<input type="radio"/>	100.0	<input type="radio"/>
# of Half Base Pts:	5		

The Airfoil component's NACA input section has the following parameters.

NACA Airfoil: The NACA airfoil description as described under the NACA Airfoil Description section.

Sharpen TE: If selected the airfoil will have a sharp trailing edge. If it is unselected the airfoil will have a base at the trailing edge. Not all airfoils can have a base. If the airfoil can not have a base, and the **Sharpen TE** radio button is unselected, a warning will be given. The mathematical description of some of the airfoils do

not include a sharp trailing edge description. In this case a portion of the rear surface is faired to a sharp point.


of Camber Line Pts: The number of points distributed along the chamber line. The points along the top and bottom surface of the airfoil are determined by projecting a line from a chamber line point perpendicular to the chamber line until it intersects with the top and bottom surface.

L.E. Distribution: The distribution clustering at the leading edge. There are three ways to specify the first spacing interval at the leading edge: 1) Float, 2) Delta %, and 3) Delta % of Avg. These types of spacing intervals are described

T.E. Distribution: Similar to the L.E. Distribution but applied to the trailing edge.

of Half Base Pts: The number of points for half the base. This field is ignored if Sharpen TE is selected.

2D Geometry Input Section



The image shows a software dialog box titled "User Defined Mold Line". It contains the following elements:


- Start Pt.:** A section with two input fields: "x" with the value "1.0" and "y" with the value "0.0".
- Leading Edge:** A list box containing the text "Leading Edge".
- # of Half Base Pts:** An input field at the bottom right containing the value "5".

The Airfoil component's 2D geometry input section has the following parameters.


Start Pt.: The x and y (actually z) coordinates for the beginning of the user defined geometry.

of Half Base Pts: The number of points for half the base. This field is ignored if the geometry has a sharp trailing edge.

Segment Menu: Right click in the **User Defined Mold Line** list to display the segment menu. The menu items of the segment menu will depend on whether a segment was clicked on or not. The below left figure is an example of a segment menu which was a result of right clicking on a non segment. The below right figure is an example of a segment menu which is a result of right clicking on a segment.



Add Segment: Select the **Add Segment** menu item to display the segment window segment selection window shown below. The segments are described in a separate section.



Delete Segment: Delete the selected segment.

Edit Segment: Edit the selected segment. The segments are described in a separate section.

Copy: Copy the selected segment.

Paste: Paste a copied segment in the selected location.

Add Break: Add a break. Breaks are described in a separate section.


Delete Break: Delete a break.

Edit Break: Edit a break. Breaks are described in a separate section.

Set LE Above: Set the leading edge location at the beginning of the selected segment. The purpose of the leading edge is to set the point at which forward segment, or cut, begins for an H grid. Also, the line which connects the first point and the leading edge becomes the chord for the 2D geometry.

Set TE Above: Set the leading edge location at the end of the selected segment. The purpose of the leading edge is to set the point at which forward segment, or cut, begins for an H grid. Also, the line which connects the first point and the leading edge becomes the chord for the 2D geometry.

AT_Airfoil_CFD




The AT_Airfoil_CFD component is the top level component for setting up a CFD run. The AT_Airfoil_CFD has two basic input quantities at top along with three addition input panels. The three input panels are Grid, CFD, and Display. The input panels will be discussed after the **Commands** menu and the basic input fields.

Menu Items

The AT_Airfoil_CFD components has two menus, Commands and Input.

Commands



Invalidate Grids: Selecting this menu item will invalidate the solution and all the grids attached to this component.

Calculate Grids: Selecting this menu item will calculate, mark, and connect all the grids.

Invalidate Solution: Selecting this will invalidate the solution only. The grids will remain.

Calculate Solution: Selecting this will begin execution of the CFD job. If the grid system has not been built then it will also calculate the grids.


Export Solution: Export the solution. Note that the CFD tool currently can not read in an exported solution. The solution formats allowed are: 1) Aero Troll (Binary), 2) EnSight (ASCII or Binary. For use by ParaView), 3) CGNS (Binary), 4) Tecplot (ASCII), 5) Plot3D (Binary), and 6) CSV (ASCII).

Export Residual: Export the residual history to a Tecplot or CSV file.

Export Turb Residual: Export the turbulence model residual history to a Tecplot or CSV file.

Export Loads: Export the loads history file to a Tecplot or CSV file.

Input



Grid/CFD/Displays: Select the type of input fields to display.

All: Display the Grid, CFD, and Display input fields.

Global Fields

<input checked="" type="checkbox"/> Auto Start:

Auto Start: When this check box is selected the CFD run will automatically start execution when a calculation is requested. Otherwise, the Exec AT CFD Dialog will be displayed with the calculation in the “paused” mode. The user must then explicitly start the run.

Grid Fields

Hole Border:	<input type="text" value="1.0E-10"/>		
Trim Passes:	<input type="text" value="1"/>	Fringe Passes:	<input type="text" value="2"/>
Fringe Upgrades:	<input checked="" type="checkbox"/> Type 1	<input checked="" type="checkbox"/> Type 2	

Hole Border: When punching a hole in the grid, any point whose distance to the surface is less than or equal to this value will be eliminated. How this value is interpreted is dependent on the geometry for which the grid punching is being done.

Trim Passes: This value indicates the number of grid layers which are stripped away after the hole punching is completed. If this value is set to zero then no layers will be stripped away.

Fringe Passes: This value indicates the number of fringe layers for points which are at the fringe edge. Fringe points get their flow values by means of interpolation from other grids.

Fringe Upgrades: These check boxes specify which points can be upgraded from a fringe point to a non fringe point if the point can not find a grid cell to interpolate from. If a fringe point can not find a grid to interpolate from, even after upgrades, then the point becomes an orphan. A CFD execution can only begin when no orphans exist.

CFD Fields

<input checked="" type="radio"/> Euler	<input type="radio"/> Laminar	<input type="radio"/> Turb (SA)	<input type="radio"/> Turb (SST)
Mu Turb Limit:	<input type="text" value="0.0"/>		
Iterations:	<input type="text" value="1000"/>		
Time Stepping	<input checked="" type="radio"/> CFL	<input type="radio"/> dt	
CFL:	<input type="text" value="5.0"/>	dt min: <input type="text" value="0.0"/>	dt max: <input type="text" value="0.0"/>
CFL Stretching:	<input type="checkbox"/>	Area Ratio: <input type="text" value="100.0"/>	Max Multiplier: <input type="text" value="20.0"/>
Turb Iterations:	<input type="text" value="1"/>		
DT Turb Mult:	<input type="text" value="1.0"/>		
Turb Huang Iter:	<input type="text" value="1"/>		
2nd Order Dis.:	<input type="text" value="2.0"/>		
4th Order Dis.:	<input type="text" value="0.04"/>		
LHS xi	<input type="radio"/> ADI	<input type="radio"/> DADI	<input checked="" type="radio"/> MDADI
LHS zeta	<input type="radio"/> ADI	<input type="radio"/> DADI	<input checked="" type="radio"/> MDADI
Xi Switch Metric	<input type="text" value="0.04"/>		
Zeta Switch Metric	<input type="text" value="0.04"/>		
ADI Mixing	Off Count	<input type="text" value="19"/>	On Count <input type="text" value="1"/>
<input type="button" value="B.C. Lagging..."/>			

Euler/Laminar/Turb (SA): Radio button to select whether an Euler, Laminar Navier Stokes (i.e. no turbulence model), or Reynolds Averaged Navier Stokes run is made. Currently only the Spalart Allmaras turbulence model is available.

Mu Turb Limit: The maximum amount of eddy viscosity which is allowed. If the value is set to zero then an upper limit is not imposed.

Iterations: The total number of iterations to run the solver for.

Time Stepping: Radio button to select if local time stepping (CFL) or constant time stepping (dt) should be used. It is important to note that local time stepping is a means of accelerating the flow and it is not time accurate. Under certain circumstances the local and constant time stepping methods can converge to different steady state solutions, if a steady state solution exists.

CFL/dt min/dt max: The CFL value to use if local time stepping is chosen. The dt min and max values specify an upper and lower band for the local time step. Regardless of the CFL value chosen, the local time step will not go above or below these values.

dt/CFL min/CFL max: Not shown in the figure above. The dt value to use if constant time stepping is chosen. The CFL min and max values specify an upper and

lower band for the local CFL value. Regardless of the dt value chosen, the local CFL number will not go above or below these values.

CFL Stretching/Area Ratio/Max Multiplier: .

Turb Iterations: The number of iterations for the turbulence model for every iteration step of the Navier Stokes solver.

DT Turb Mult: The dt multiplier for the turbulence model. The dt used by the turbulence model is equal to the dt of the Navier Stokes multiplied by this value.

Turb Huang Iter: The number of Huang sub iterations for the turbulence model.

2nd Order Dis.: The value of the 2nd order dissipation.

4th Order Dis.: The value of the 4th order dissipation.

LHS xi: The solution methodology for the left hand side (LHS) implicit matrix in the xi direction, (i.e. i direction).


LHS zeta: The solution methodology for the left hand side (LHS) implicit matrix in the zeta direction, (i.e. k direction).

Xi Switch Metric: The MDADI metric in the xi direction (i.e. i direction) at which an ADI solution methodology is used instead of the DADI method for a given zeta line.

Zeta Switch Metric: The MDADI metric in the zeta direction (i.e. k direction) at which an ADI solution methodology is used instead of the DADI method for a given xi line.

ADI Mixing/Off Count/On Count: Used for DADI and MDADI methods. The off count equals the number of iterations for which the selected DADI or MDADI method is used. The on count equals the number of iterations for which the ADI method is used.

B.C. Lagging: The boundary condition lagging window is shown below. These values apply to the ADI implicit method only. The DADI method always lags the boundary conditions. When a boundary condition is not lagged it is included in the implicit matrix. This speeds up the solution. Lagging a boundary condition will slow down the convergence rate but increase the stability.



Display Fields

Resid Iterations:	<input type="text" value="1"/>		
Force Iterations:	<input type="text" value="20"/>		
Update Iterations:	<input type="text" value="100"/>		
Size of Max. Resid Pts	<input type="text" value="5"/>	# of Max. Resid Pts	<input type="text" value="200"/>
Size of Marked Pts	<input type="text" value="5"/>		

Resid Iterations: The iteration interval at which the residual history is upgraded. This value should be increased for runs which require many iterations. This value may also be changed by means of the Exec AT CFD Dialog. Each residual history entry does require a tiny bit of memory from the user interface. Over time, this does add up.

Force Iterations: The iteration interval at which the force and moment history is upgraded. This value should be increased for runs which require many iterations. This value may also be changed by means of the Exec AT CFD Dialog. Each force and moment history entry does require a tiny bit of memory from the user interface. Over time, this does add up.

Update Iterations: The iteration interval at which the main window's contour plot is upgraded. This value should be increased for runs which require many iterations. This value may also be changed by means of the Exec AT CFD Dialog. The amount of memory requirements required by the contour plots do not accumulate over time. However, extracting and drawing the contour plots does take time, therefore the CFD execution will slow down as more updates are requested.

Size of Max. Resid Pts: The location of the maximum residual over a number of iterations is plotted in the main window's by means of a dot along with the contour plot. This value specifies the default dot size used by all the grids. Each grid can override this value.

of Max. Resid Pts: The location of the maximum residual over a number of iterations is plotted in the main window's by means of a dot along with the contour plot. This value specifies how many of the previous iteration maximum residuals are plotted.

Size of Marked Pts: This parameter defines the default dot size for marked points. This includes cut, fringe, orphans, trimmed, boundary, and upgraded points.

CFD Grid Group (Airfoil)

Edit Window

CFD Grid Group

Commands Vol. Grid: Grid[0] View Settings

Grid Type: C

Surface Grid

Aft Segment
Airfoil::Bottom Surface
Airfoil::Top Surface
Aft Segment

Forward Length: 1.0 Forward Angle: 0.0
Aft Length: 1.0 Aft Angle: 0.0

Keep Deactive Components Connected

Volume Grid Input

Zeta Grid
Geometric(S):[0]

Beginning Grid B.C.: Auto
Ending Grid B.C.: Auto

Sub Steps: 1
Xi Volume Smoothing: 0.0
Xi Slope Smoothing: 0.0

Zeta Spread Start: 0.0 Percentage
Zeta Spread End: 0.0 Percentage

Avg. Vol. Weighting: 0.0
Metric Multiplier: 0.1
2nd Order Dis.: 0.0

Forward Spread... Aft Spread...

Inc. Base Grid:

Cut Pts		Trimmed Pts	
Fringe Pts		Boundary Pts	
Orphan Pts		Upgraded Pts	

CFD Input

Surface B.C. None

Accept Accept All Revert Revert All

The CFD Grid Group for Airfoils is the component which contains the grid for an airfoil geometry component. A CFD Grid Group for Airfoils can only be created from an AT_Airfoil_CFD component. The CFD Grid Group for Airfoil is the means by which the surface grid, volume grid, and CFD boundary conditions for the airfoil are specified. Currently only one grid can be created through this interface. Future interfaces may allow for multiple grids to be created to envelope an airfoil.

Menu Items

The CFD Grid Group for Airfoils component has four menus; Commands, Vol. Grid, View and Settings.

Commands

Add Volume Grid
Delete Volume Grid
Rename Volume Grid...
Invalidate Grid...
Calculate Grid
Invalidate All Grids...
Calculate All Grids
Calculate Solution
Export All Solutions...
Export Solution...
Export Residual...
Export Turb Residual...
Export Loads...

Rename Volume Grid: Rename the current grid. The default name is Grid(i), where i is the index of a grid.

Invalidate Grid: Invalidate the current grid.

Calculate Grid: Generate a new grid if the current grid is invalid.

Invalidate All Grids: Invalidate all the grids associated with this grid group. Currently, since only one grid is allowed, this command has the same outcome as selecting the Invalidate Grid command.

Calculate All Grids: Calculate all the grids associated with this grid group. Currently, since only one grid is allowed, this command has the same outcome as selecting the Calculate Grid command.

Calculate Solution: A convenience command which executes the parent AT_Airfoil_CFD Calculate Solution command.

Export All Solutions: Export the solution for all the grids associated with this grid group. The solution formats allowed are: 1) Aero Troll (Binary), 2) EnSight (ASCII or Binary. For use by ParaView), 3) CGNS (Binary), 4) Tecplot (ASCII), 5) Plot3D (Binary), and 6) CSV (ASCII).

Export Solution: Export the solution for the current grid. The solution formats allowed are: 1) Aero Troll (Binary), 2) EnSight (ASCII or Binary. For use by ParaView), 3) CGNS (Binary), 4) Tecplot (ASCII), 5) Plot3D (Binary), and 6) CSV (ASCII).

Export Residual: Export the residual for the current grid to a Tecplot or CSV file.


Export Turb Residual: Export the turbulence model residual history for the current grid to a Tecplot or CSV file.

Export Loads: Export the loads history for the current grid to a Tecplot or CSV file.

Vol. Grid

The Vol. Grid combo box allows for the identification of the current grid. Since, currently, only one grid is associated with the grid group, this combo box does not do anything.

View



Points->Show/Hide Neg. Jacobian: .Show or hide grid point markers which identify negative cell volumes.

Points->Show/Hide Cut: .Show or hide grid point markers which identify the grid points which were cut because they lie within a geometry or a user specified buffer zone.

Points->Show/Hide Trimmed: .Show or hide grid point markers which identify the grid points which were trimmed away from a cut.

Points->Show/Hide Boundary: Show or hide grid point markers which identify a fringe boundary.

Points->Show/Hide Fringe: Show or hide grid point markers which identify fringe grid points.

Points->Show/Hide Upgraded: Show or hide grid point markers which identify fringe points which were upgraded to interior points because interpolation parameters for it could not be found.

Points->Show/Hide Orphan: Show or hide grid point markers which identify fringe points for which interpolation parameters could not be found.

Points->Show/Hide Max. CFL Resid: Show or hide grid point markers which identify the grid points at which the maximum residual based on a CFD criteria occurred.

Points->Show/Hide Max. Dt Resid: Show or hide grid point markers which identify the grid points at which the maximum residual based on a constant global time step occurred.

Points->Show/Hide Max. Solution: Show or hide grid point markers which identify the grid points at which the maximum delta Q occurred.

Show/Hide Grid: Show or hide the entire grid.

Show/Hide Wireframe: Show or hide the grid wireframe.

Show/Hide Blanked Pts: Show or hide cells which are iBlanked.

Settings

Neg. Jacobian...
Cut...
Trimmed...
Boundary...
Fringe...
Upgraded...
Orphan...
Max. CFL Resid...
Max. Dt Resid...
Max. Solution...

The setting menu allows for changing the size and color of grid point markers. If -1 is used for the size, then the default size from the parent AT_Airfoil_CFD **Size of Marked Pts.** or **Size of Max. Resid Pts.** is used.


Grid Type Field



Grid Type: C

The Grid Type Field allows for the specification of an O, C, or H grid.

Surface Grid Fields



Surface Grid

Aft Segment
Airfoil::Bottom Surface
Airfoil::Top Surface
Aft Segment

Forward Length: 1.0 Forward Angle: 0.0
Aft Length: 1.0 Aft Angle: 0.0

Keep Deactive Components Connected

Surface Grid Segments: The reader is referred to the examples for a description of this.

Forward Length: The length of the forward segment for an H grid.

Forward Angle: The angle of the forward segment with respect to the horizontal for an H grid.

Aft Length: The length of the aft segment for an H or C grid.

Aft Angle: The angle of the aft segment with respect to the horizontal for an H or C grid.

Keep Deactive Components Connected: Currently, segments can not be deactivated, therefore this setting should remain selected.

Volume Grid Fields

Volume Grid Input

Zeta Grid

Geometric(S):[0]

Beginning Grid B.C.: Auto

Ending Grid B.C.: Auto

Sub Steps: 1

Xi Volume Smoothing: 0.0

Xi Slope Smoothing: 0.0

Zeta Spread Start: 0.0 Percentage

Zeta Spread End: 0.0 Percentage

Avg. Vol. Weighting: 0.0

Metric Multiplier: 0.1

2nd Order Dis.: 0.0

Forward Spread... Aft Spread...

Inc. Base Grid

Cut Pts Trimmed Pts

Fringe Pts Boundary Pts

Orphan Pts Upgraded Pts

Zeta Grid Segments: The reader is referred to the examples for a description of this.

Beginning Grid B.C.: The beginning grid boundary condition specifies how the beginning grid edge should march off the surface and applies to H and C grids. The five choices for the beginning grid boundary condition are: 1) Auto, 2) Float, 3) Normal, 4) Fixed X, and 5) Fixed Z. The Auto b.c. is the same as the Normal b.c. and specifies that the entire edge should be normal to the surface. The Float b.c. specifies that the edge should leave the surface normal but then may curve. The Fixed X b.c. specifies that the grid edge should have a constant x value in the grid coordinate system. The Fixed Z b.c. specifies that the grid edge should have a constant z value in the grid coordinate system.

Ending Grid B.C.: The ending grid boundary condition specifies how the ending grid edge should march off the surface and applies to H and C grids. The five choices for the ending grid boundary condition are: 1) Auto, 2) Float, 3) Normal, 4) Fixed X, and 5) Fixed Z. The Auto b.c. is the same as the Normal b.c. and specifies that the entire edge should be normal to the surface. The Float b.c. specifies that the

edge should leave the surface normal but then may curve. The Fixed X b.c. specifies that the grid edge should have a constant x value in the grid coordinate system. The Fixed Z b.c. specifies that the grid edge should have a constant z value in the grid coordinate system.

Sub Steps: The number of iterations that occurs in the zeta (off body) direction for a xi (circumferential) grid line to be drawn. This value is described in the Gridding section earlier in this manual.

Xi Volume Smoothing: Grid smoothing based on the grid volume. This value is described in the Gridding section earlier in this manual.

Xi Slope Smoothing: Grid smoothing based on the cell wall slopes. This value is described in the Gridding section earlier in this manual.

Zeta Spread Start: The zeta spread start parameter allows for the user to specify how the grid spacing between points on a xi surface changes as the grid marches away from the surface. This value is described in the Gridding section earlier in this manual.

Zeta Spread End: The zeta spread end parameter allows for the user to specify how the grid spacing between points on a xi surface changes as the grid marches away from the surface. This value is described in the Gridding section earlier in this manual.

Avg. Vol. Weighting: Parameter to set a weighing value for averaging adjacent grid cell volumes. This value is described in the Gridding section earlier in this manual.

Metric Multiplier: A parameter which should be left unchanged.

2nd Order Dis: A 2nd order dissipation value. This parameter should be left unchanged.

Forward Spread: An advanced feature which will be described at a later date.

Aft Spread: An advanced feature which will be described at a later date.

Inc. Base Grid: If a base exists, deactivate the base grid. If deactivated, the base topology is included in the hyperbolic grid generation process.

Point Count: A count of the number of cut, trimmed, fringe, fringe boundary, orphan, and upgraded points. These are display parameters only and may not be edited.

CFD Input Fields


CFD Input

Surface B.C.	None	▼
Farfield B.C.	None	▼

Surface B.C.: The boundary condition to use for the surface. The four choices are: 1) None, 2) Auto, 3) Slip, and 4) No Slip. For a solution execution to occur, a boundary value other than None must be chosen. The boundary conditions are explained under the B.C. Settings section earlier in the manual.

Farfield B.C.: The boundary condition to use for the far field. The five choices are: 1) None, 2) Freestream, 3) Characteristic, 4) Inlet/Outlet, and 5) Fringe. For a solution execution to occur, a boundary value other than None must be chosen. The boundary conditions are explained under the B.C. Settings section earlier in the manual.

CFD 2D Grid Block



Menu Items

The CFD 2D Grid Block component has three menus; Commands, View and Settings.

Commands

Invalidate Grid...
Calculate Grid
Invalidate All Grids...
Calculate All Grids
Calculate Solution
Export Solution...
Export Residual...
Export Turb Residual...
Export Loads...

Invalidate Grid: Invalidate the grid.

Calculate Grid: Generate a new grid if the grid is invalid.

Invalidate All Grids: Invalidate all the grids associated with this grid group. Currently, since only one grid is allowed, this command has the same outcome as selecting the Invalidate Grid command.

Calculate All Grids: Calculate all the grids associated with this grid group. Currently, since only one grid is allowed, this command has the same outcome as selecting the Calculate Grid command.

Calculate Solution: A convenience command which executes the parent AT_Airfoil_CFD Calculate Solution command.

Export Solution: Export the solution for the grid. The solution formats allowed are: 1) Aero Troll (Binary), 2) EnSight (ASCII or Binary. For use by ParaView), 3) CGNS (Binary), 4) Tecplot (ASCII), 5) Plot3D (Binary), and 6) CSV (ASCII).

Export Residual: Export the residual for the grid to a Tecplot or CSV file.

Export Turb Residual: Export the turbulence model residual history for the grid to a Tecplot or CSV file.

Export Loads: Export the loads history for the grid to a Tecplot or CSV file.

View

Points ▶
Hide Grid
Hide Wireframe
Show Blanked Cells

Points->Show/Hide Cut: .Show or hide grid point markers which identify the grid points which were cut because they lie within a geometry or a user specified buffer zone.

Points->Show/Hide Trimmed: .Show or hide grid point markers which identify the grid points which were trimmed away from a cut.

Points->Show/Hide Boundary: Show or hide grid point markers which identify a fringe boundary.

Points->Show/Hide Fringe: Show or hide grid point markers which identify fringe grid points.

Points->Show/Hide Upgraded: Show or hide grid point markers which identify fringe points which were upgraded to interior points because interpolation parameters for it could not be found.

Points->Show/Hide Orphan: Show or hide grid point markers which identify fringe points for which interpolation parameters could not be found.

Points->Show/Hide Max. CFL Resid: Show or hide grid point markers which identify the grid points at which the maximum residual based on a CFD criteria occurred.

Points->Show/Hide Max. Dt Resid: Show or hide grid point markers which identify the grid points at which the maximum residual based on a constant global time step occurred.

Points->Show/Hide Max. Solution: Show or hide grid point markers which identify the grid points at which the maximum delta Q occurred.

Show/Hide Grid: Show or hide the entire grid.

Show/Hide Wireframe: Show or hide the grid wireframe.


Show/Hide Blanked Cells: .Show or hide cells which are iBlanked.

Settings



The setting menu allows for changing the size and color of grid point markers. If -1 is used for the size, then the default size from the parent AT_Airfoil_CFD **Size of Marked Pts.** or **Size of Max. Resid Pts.** is used.

Surface Grid Fields



Xi Surface Grid Segments: The reader is referred to the examples for a description of this.

Zeta Surface Grid Segments: The reader is referred to the examples for a description of this.

Volume Grid Fields

Reflect	<input type="checkbox"/> YZ Plane	<input type="checkbox"/> XY Plane	
Cut Pts	<input type="text"/>	Trimmed Pts	<input type="text"/>
Fringe Pts	<input type="text"/>	Boundary Pts	<input type="text"/>
Orphan Pts	<input type="text"/>	Upgraded Pts	<input type="text"/>

Reflect YZ Plane: Reflect the volume grid about the yz (vertical) plane.

Reflect XY Plane: Reflect the volume grid about the xy (horizontal) plane.

Point Count: A count of the number of cut, trimmed, fringe, fringe boundary, orphan, and upgraded points. These are display parameters only and may not be edited.

CFD Input Fields

CFD Input	
Outer B.C.	None ▼
Inner B.C.	None ▼

Outer B.C.: The boundary condition to use for the outer boundary. The five choices are: 1) None, 2) Freestream, 3) Characteristic, 4) Inlet/Outlet, and 5) Fringe. For a solution execution to occur, a boundary value other than None must be chosen. The boundary conditions are explained under the B.C. Settings section earlier in the manual.

Inner B.C.: The boundary condition to use for the inner. The eight choices are: 1) None, 2) Freestream, 3) Characteristic, 4) Inlet/Outlet, 5) Fringe, 6) Auto, 7) Slip, and 8) No Slip. For a solution execution to occur, a boundary value other than None must be chosen. The boundary conditions are explained under the B.C. Settings section earlier in the manual.

Exec AT CFD Dialog

The screenshot shows the 'Exec AT CFD Dialog' window. It features a blue title bar with the text 'Exec AT CFD Dialog' and a close button. Below the title bar is a tabbed interface with tabs for 'AT Cntrl', 'Run Cntrl', 'Flow Field', 'Resid', 'Turb', 'For+Mom', and 'History'. The 'AT Cntrl' tab is selected. The main area contains several input fields: 'Max. Iter.' (1000), 'Stepping Iter.' (1), 'Update Resid. Iter.' (1), 'Update For. and Mom. Iter.' (10), 'Update Display Iter.' (20), '# of Max. Resid Pts' (200), and 'Size of Max. Resid Pts' (5). At the bottom, there are buttons for 'Accept', 'Reset', and a checkbox labeled 'Automatically close dialog?'. Below these are a row of buttons: 'Run', 'Step', 'Renew', 'Cancel', 'Close', 'Open', and 'Save'.

The Exec AT CFD dialog is the main control center for running a CFD job. When a CFD job is executed either from an Analysis or AT_Airfoil_CFD component, the Exec AT CFD dialog will be displayed.

Exec AT CFD Dialog Fields

Accept: Accept all the fields.

Reset: Reset all fields to the previous accepted values.

Automatically close dialog: When set the dialog will automatically close when execution is completed.

Run: Execute the CFD application till maximum number of iterations is completed.

Pause: Pause the CFD application.

Step: Execute the CFD application till the number of stepping iterations is completed.

Renew: Invalidate the CFD solution.

Cancel: Invalidate the CFD solution and close the Exec AT CFD dialog.

Close: Close the Exec AT CFD dialog.

Open: Open a solution file. Currently this is disabled.

Save: Save a solution file. Currently this is disabled.

Exec AT CFD AT Cntrl Fields

Max. Iter.: The total number of iterations to run the solver for.

Stepping Iter.: The number of iterations which will be executed when the **Step** button is pressed.

Update Resid Iter.: The iteration interval at which the residual history is upgraded. This value should be increased for runs which require many iterations. Each residual history entry does require a tiny bit of memory from the user interface. Over time, this does add up.

Update For. and Mom. Iter.: The iteration interval at which the force and moment history is upgraded. This value should be increased for runs which require many iterations. Each force and moment history entry does require a tiny bit of memory from the user interface. Over time, this does add up.

Update Display Iter.: The iteration interval at which the main window's contour plot is upgraded. This value should be increased for runs which require many iterations. The amount of memory requirements required by the contour plots do not accumulate over time. However, extracting and drawing the contour plots does take time, therefore the CFD execution will slow down as more updates are requested.

of Max. Resid Pts: The location of the maximum residual over a number of iterations is plotted in the main window's by means of a dot along with the contour plot. This value specifies how many of the previous iteration maximum residuals are plotted.

Size of Max. Resid Pts: The location of the maximum residual over a number of iterations is plotted in the main window's by means of a dot along with the contour plot. This value specifies the default dot size used by all the grids. Each grid can override this value.

Exec AT CFD Run Cntrl Fields

The screenshot shows the 'Exec AT CFD Dialog' window with the following configuration:

- AT Cntrl** (selected tab)
- Euler**:
- Laminar**:
- Turbulent (SA)**:
- Turbulent (SST)**:
- Time Stepping**:
 - CFL**:
 - dt**:
- CFL:** 90.0
- dt min:** 0.0
- dt max:** 0.0
- CFL Stretching:**
- CFL Area Ratio:** 100.0
- CFL Area Max Multiplier:** 20.0
- dis. 2nd:** 2.0
- dis. 4th:** 0.04
- Turb Iterations:** 1
- Turb Huang Iter:** 1
- DT Turb Mult:** 1.0
- Mu Turb Limit:** 0.0
- LHS xi**: ADI DADI MDADI
- LHS zeta**: ADI DADI MDADI
- Xi Switch Metric**: 0.04
- Zeta Switch Metric**: 0.04
- ADI Mixing: Off Count**: 19
- ADI Mixing: On Count**: 1

Buttons: Accept, Reset, Automatically close dialog?, Run, Step, Renew, Cancel, Close, Open, Save

Euler/Laminar/Turb (SA): Radio button to select whether an Euler, Laminar Navier Stokes (i.e. no turbulence model), or Reynolds Averaged Navier Stokes run is made. Currently only the Spalart Allmaras turbulence model is available.

Time Stepping: Radio button to select if local time stepping (CFL) or constant time stepping (dt) should be used. It is important to note that local time stepping is a means of accelerating the flow and it is not time accurate. Under certain

circumstances the local and constant time stepping methods can converge to different steady state solutions, if a steady state solution exists.

CFL/dt min/dt max: The CFL value to use if local time stepping is chosen. The dt min and max values specify an upper and lower band for the local time step. Regardless of the CFL value chosen, the local time step will not go above or below these values.

dt/CFL min/CFL max: Not shown in the figure above. The dt value to use if constant time stepping is chosen. The CFL min and max values specify an upper and lower band for the local CFL value. Regardless of the dt value chosen, the local CFL number will not go above or below these values.

CFL Stretching/Area Ratio/Max Multiplier: .

2nd Order Dis.: The value of the 2nd order dissipation.

4th Order Dis.: The value of the 4th order dissipation.

Turb Iterations: The number of iterations for the turbulence model for every iteration step of the Navier Stokes solver.

Turb Huang Iter: The number of Huang sub iterations for the turbulence model.

DT Turb Mult: The dt multiplier for the turbulence model. The dt used by the turbulence model is equal to the dt of the Navier Stokes multiplied by this value.

Mu Turb Limit: The maximum amount of eddy viscosity which is allowed. If the value is set to zero then an upper limit is not imposed.

LHS xi: The solution methodology for the left hand side (LHS) implicit matrix in the xi direction, (i.e. i direction).

LHS zeta: The solution methodology for the left hand side (LHS) implicit matrix in the zeta direction, (i.e. k direction).

Xi Switch Metric: The MDADI metric in the xi direction (i.e. i direction) at which an ADI solution methodology is used instead of the DADI method for a given zeta line.

Zeta Switch Metric: The MDADI metric in the zeta direction (i.e. k direction) at which an ADI solution methodology is used instead of the DADI method for a given xi line.

ADI Mixing/Off Count/On Count: Used for DADI and MDADI methods. The off count equals the number of iterations for which the selected DADI or MDADI

method is used. The on count equals the number of iterations for which the ADI method is used.

Exec AT CFD Flow Field Fields

Parameter	Value
sRef	1.0
lRef	1.0
bRef	1.0
xMom	0.0
yMom	0.0
zMom	0.0
Mach	0.5
Gamma	1.4
U	0.9993908270190958
V	0.0
W	0.03489949670250097
Tinf	518.67
Re (per len.)	3000000.0
Pr	0.72
Pr Turb	0.9
SA Turb Eddy Vis	3.0

sRef: The reference area used to non-dimensionalize the aerodynamic forces and moments. The value must be greater than zero.

lRef: The reference length used to non-dimensionalize the longitudinal aerodynamic moments. The value must be greater than zero.

bRef: The reference length used to non-dimensionalize the lateral aerodynamic moments. The value must be greater than or equal to zero. If the value is equal to zero then *lRef* will substitute for *bRef*.

xMom: The x value for the moment center measured in the local coordinate system. Positive is rearward.

yMom: The y value for the moment center measured in the local coordinate system. Positive is starboard.

zMom: The z value for the moment center measured in the local coordinate system.
Positive is up.

Mach: The Mach number for the analysis.

Gamma: The ratio of the specific heats.

U: The freestream u component of the velocity, non-dimensionalized by the speed of sound.

V: The freestream v component of the velocity, non-dimensionalized by the speed of sound.

W: The freestream w component of the velocity, non-dimensionalized by the speed of sound.

Tinf: The freestream temperature in Rankin.


Re (per len.): Reynolds number per length.

Pr: Laminar Prandtl number.

Pr Turb: Turbulent Prandtl number.

SA Turb Eddy Vis: Spalart Allmaras freestream turbulence value.

Exec AT CFD Resid Fields



Grid Group, Grid: Select the grid group and grid for which the residual will be displayed.

Include in Global Plot: Include this data in the data group for which the **Plot All** button acts.

CFL rAvg and rMax: The average and maximum right hand side residual. The residual is multiplied by a metric which represents a CFL value of 1.0.


DT rAvg and rMax: The average and maximum right hand side residual. The residual is multiplied by a metric which represents a dt value of 1.0.

sAvg and sMax: The average and maximum delta q by which the solution is updated.

Plot This: Plot this data set only.

Plot All: Plot all data sets for which Include in **Global Plot** checkbox is selected.

Exec AT CFD Turb Fields



Grid Group, Grid: Select the grid group and grid for which the residual will be displayed.

Include in Global Plot: Include this data in the data group for which the **Plot All** button acts.

CFL rAvg[0] and rMax[0]: The average and maximum right hand side residual for the first turbulence iteration. The residual is multiplied by a metric which represents a CFL value of 1.0.

DT rAvg[0] and rMax[0]: The average and maximum right hand side residual for the first turbulence iteration. The residual is multiplied by a metric which represents a dt value of 1.0.

sAvg[0] and sMax[0]: The average and maximum delta q for the first turbulence iteration by which the solution is updated.

CFL rAvg[n] and rMax[n]: The average and maximum right hand side residual for the last turbulence iteration. The residual is multiplied by a metric which represents a CFL value of 1.0.


DT rAvg[n] and rMax[n]: The average and maximum right hand side residual for the last turbulence iteration. The residual is multiplied by a metric which represents a dt value of 1.0.

sAvg[n] and sMax[n]: The average and maximum delta q for the last turbulence iteration by which the solution is updated.

Plot This: Plot this data set only.

Plot All: Plot all data sets for which Include in **Global Plot** checkbox is selected.

Exec AT CFD For+Mom Fields



Grid Group, Grid: Select the grid group and grid for which the residual will be displayed.

Include in Global Plot: Include this data in the data group for which the **Plot All** button acts.


P., Vis., Tot.: Choose if the pressure, viscous, and/or total (pressure+viscous) coefficients should be plotted.

CX, CY, CZ, Cl, Cm, and Cn: Select the force or moment coefficient to plot. Note that this value may not agree with the load results for a component. The loads presented in this dialog are a result of integrating the surface pressures and wall shear stresses over grid points identified as surface points by the boundary conditions within the CFD code. This result may differ from loads obtained by integrating the pressures and shear stresses on the surface grids used by components in the Aero Troll user interface.

Plot This: Plot this data set only.

Plot All: Plot all data sets for which Include in **Global Plot** checkbox is selected.

Exec AT CFD History Fields



The above figure shows the history of the run.

TOOLS/CALCULATORS

The latest version of Aero Troll introduces the following tools and calculators.

- 1) Standard Atmosphere
- 2) y^+
- 3) Isentropic
- 4) Shock
- 5) Expansion

Standard Atmosphere

The Standard Atmosphere tool allows for various atmospheric quantities to be calculated using the 1976 U.S. Standard Atmosphere. The coding is based on the Atmosphere program from Public Domain Aeronautical Software, www.pdas.com/atmos.html.



The screenshot shows a software window titled "Standard Atmosphere" with a close button in the top right corner. The window is divided into two main sections: "Input:" and "Output:".

Input:

Altitude	<input type="text"/>	ft
Velocity	<input type="text"/>	ft/s
Reference Length	<input type="text"/>	ft

Output:

Pressure	<input type="text"/>	lb/ft ²
Density	<input type="text"/>	slug/ft ³
Temperature	<input type="text"/>	°R
Speed of Sound	<input type="text"/>	ft/s
1/Speed of Sound	<input type="text"/>	s/ft
Dynamic Viscosity (μ)	<input type="text"/>	slug/(ft s)
Kinematic Viscosity (ν)	<input type="text"/>	ft ² /s
Velocity	<input type="text"/>	ft/s
Mach	<input type="text"/>	Mach
Dynamic Pressure	<input type="text"/>	lb/ft ²
Reynolds Number/Length	<input type="text"/>	/ft
Reynolds Number	<input type="text"/>	
y for y+ of 1	<input type="text"/>	ft

Altitude: The altitude for which to calculate the results.

Velocity: The velocity for which to calculate the results.

Reference Length: The reference length for which to calculate the Reynolds Number and off surface spacing for y^+ of 1.

Pressure: The standard atmospheric pressure at the indicated altitude.

Density: The standard atmospheric density at the indicated altitude.

Temperature: The standard atmospheric temperature for the indicated altitude.

Speed of Sound: The standard atmospheric speed of sound for the indicated altitude.

1.0/Speed of Sound: The inverse of the calculated speed of sound.

Dynamic Viscosity (μ): The standard atmospheric dynamic viscosity for the indicated altitude.

Kinematic Viscosity (ν): The standard atmospheric kinematic viscosity for the indicated altitude.

Velocity: The indicated velocity.

Mach: The Mach number for the indicated altitude and velocity.

Dynamic Pressure: The dynamic pressure for the indicated altitude and velocity.


Reynolds Number/Length: The Reynolds number per length calculated for the indicated altitude and velocity.

Reynolds Number: The Reynolds number calculated for the indicated altitude, velocity, and length scale.

y for y^+ of 1: The first off surface grid spacing for the calculated Reynolds number and indicated length scale.

Y+

The y+ tool is a means of estimating the first off surface grid spacing for turbulent flow. The methodology uses von Karman's turbulent skin friction equation for flat plates, also known as the Karman-Kempf formula



The screenshot shows a software window titled "Y+" with a blue border and a close button in the top right corner. The window is divided into two main sections: "Input:" and "Output:".

Input:

- Reynolds Number:** A text input field.
- Reference Length:** A text input field followed by a dropdown menu currently showing "ft".
- x:** A text input field followed by a dropdown menu currently showing "ft".
- y+:** A text input field.

Output:

- Re_x:** A text input field.
- y:** A text input field followed by a dropdown menu currently showing "ft".

Reynolds Number: The Reynolds number for which to calculate the results.

Reference Length: The reference length for the Reynolds number.

x: The x position at which to calculate the off surface grid spacing.

y+: The y+ value for which to calculate the results.

Re_x: The Reynolds number at the x position.

y: The off surface grid spacing at the specified x position for the given y+ value.

Iisentropic

The Iisentropic Calculator calculates the flow values between two states using the isentropic flow relations for a steady perfect gas flow. The reader is referred to NACA Report 1135.

The screenshot shows a software window titled "Iisentropic Calculator". It is divided into three main sections: "Input:", "Flow Values:", and "Area Values:".

- Input:** Contains text boxes for "Gamma" (with the value 1.4), "Mach1", and "Mach2".
- Flow Values:** Contains four rows of calculations. Each row has a text box on the left, a radio button in the middle, and a text box on the right. The radio buttons are labeled "T2/T1", "a2/a1", "p2/p1", and "p2/p1". The text boxes on the right are labeled "Mach2".
- Area Values:** Contains one row with a text box on the left, a radio button in the middle, and a text box on the right. The radio button is labeled "A2/A1". Below this row, the text "Mach3 for A2/A1" is displayed above another text box.

Gamma: The ratio of specific heats.

Mach1: The Mach number for the initial state.

Mach2: The Mach number for the final state. The final state Mach number is used for one of the subsequent calculations only if the respective Mach2 radio button is chosen.

T2/T1: The temperature ratio between the final and initial state. If the **Mach2** radio button is chosen then the T2/T1 value is calculated using the final state Mach number from the Input section. If the **T2/T1** radio button is selected then the final state Mach number is calculated using the T2/T1 value provided by the user.

a2/a1: The speed of sound ratio between the final and initial state. If the **Mach2** radio button is chosen then the a2/a1 value is calculated using the final state Mach number from the Input section. If the **a2/a1** radio button is selected then the final state Mach number is calculated using the a2/a1 value provided by the user.

p2/p1: The pressure ratio between the final and initial state. If the **Mach2** radio button is chosen then the p2/p1 value is calculated using the final state Mach number from the Input section. If the **p2/p1** radio button is selected then the final state Mach number is calculated using the p2/p1 value provided by the user.

ρ_2/ρ_1 : The density ratio between the final and initial state. If the **Mach2** radio button is chosen then the ρ_2/ρ_1 value is calculated using the final state Mach number from the Input section. If the ρ_2/ρ_1 radio button is selected then the final state Mach number is calculated using the ρ_2/ρ_1 value provided by the user.

A_2/A_1 : The area ratio between the final and initial state. For a given area ratio, two possible final state Mach numbers exist, a subsonic and a supersonic value. If the **Mach2** radio button is chosen then the A_2/A_1 value is calculated using the final state Mach number from the Input section. If the **A2/A1** radio button is selected then the final state Mach number is calculated using the A_2/A_1 value provided by the user. The Mach2 and Mach3 fields associated with the A_2/A_1 value represent the subsonic and supersonic values respectively.

Shock

The Shock Calculator calculates flow quantities associated with normal, oblique, and conical shocks. The reader is referred to NACA Report 1135.

Shock Calculator

Input:
Mach Gamma

Normal Shock:
Mach2
p2/p1 T2/T1
V2/V1 p02/p01
ρ2/ρ1 aStar2/aStar1

Wedge Shock:
Wedge Angle (deg.) Wedge Angle Shock Angle
Shock Angle (deg.) Mach2
p2/p1 T2/T1
V2/V1 p02/p01
ρ2/ρ1

Cone Shock:
Cone Angle (deg.) Cone Angle Shock Angle
Shock Angle (deg.) Mach2
p2/p1 T2/T1
V2/V1 p02/p01
ρ2/ρ1
Surface Mach3
p3/p1 T3/T1
V3/V1 p03/p01
ρ3/ρ1

Mach: The upstream Mach number.

Gamma: The ratio of specific heats.

Normal Shock

Mach2: Downstream Mach number.

p2/p1: The ratio of downstream pressure to upstream pressure.

T2/T1: The ratio of downstream temperature to upstream temperature.

$V2/V1$: The ratio of downstream velocity to upstream velocity.

$p02/p01$: The ratio of downstream stagnation pressure to upstream stagnation pressure.

$\rho2/\rho1$: The ratio of downstream density to the upstream density.

$aStar2/aStar1$: The ratio of upstream a^* to downstream a^* .

Wedge Shock

Wedge Angle (deg.): If the **Wedge Angle** radio button is selected then the surface half angle of the wedge in degrees. If the **Shock Angle** radio button is selected then the half angle of the shock in degrees.

Shock Angle (deg.): If the **Wedge Angle** radio button is selected then the calculated shock half angle in degrees. If the **Shock Angle** radio button is selected then the calculated half angle of the wedge surface in degrees.

Mach2: Downstream Mach number.

$p2/p1$: The ratio of downstream pressure to upstream pressure.

$T2/T1$: The ratio of downstream temperature to upstream temperature.

$V2/V1$: The ratio of downstream velocity to upstream velocity.

$p02/p01$: The ratio of downstream stagnation pressure to upstream stagnation pressure.

$\rho2/\rho1$: The ratio of downstream density to the upstream density.

Cone Shock

Cone Angle (deg.): If the **Cone Angle** radio button is selected then the surface half angle of the cone in degrees. If the **Shock Angle** radio button is selected then the half angle of the conical shock in degrees.

Cone Angle (deg.): If the **Cone Angle** radio button is selected then the calculated conical shock half angle in degrees. If the **Shock Angle** radio button is selected then the calculated half angle of the cone surface in degrees.

Mach2: The Mach number behind the conical shock.

$p2/p1$: The ratio of the pressure behind the conical shock to upstream pressure.

$T2/T1$: The ratio of the temperature behind the conical shock to upstream temperature.

$V2/V1$: The ratio of the velocity behind the conical shock to upstream velocity.

$p02/p01$: The ratio of the stagnation pressure behind the conical shock to upstream stagnation pressure.

$\rho2/\rho1$: The ratio of the density behind the conical shock to the upstream density.

$Mach3$: The surface Mach number.

$p3/p1$: The ratio of the surface pressure to upstream pressure.

$T3/T1$: The ratio of the surface temperature to upstream temperature.


$V3/V1$: The ratio of the surface velocity to upstream velocity.

$p03/p01$: The ratio of the surface stagnation pressure to upstream stagnation pressure.

$\rho3/\rho1$: The ratio of the surface density to the upstream density.

Expansion

The Expansion Calculator allows for the downstream values of a Prandtl-Meyer Expansion fan to be calculated.



The screenshot shows a software window titled "Expansion Calculator". The interface is divided into an "Input:" section and a "Output:" section. In the "Input:" section, there are four rows of input fields: "Mach" (with a text box), "Surface Angle (deg.)" (with a text box), "Mach2" (with a text box), and "p2/p1" (with a text box). To the right of these fields are labels: "Gamma" (with a text box containing "1.4"), "p2/p1" (with a text box), "T2/T1" (with a text box), and "V2/V1" (with a text box). The "Output:" section is currently empty.

$Mach$: The upstream Mach number.

$Gamma$: The ratio of specific heats.

$Surface Angle (deg.)$: The angle of the surface with respect to the horizontal.

$Mach2$: The downstream Mach number after the expansion wave.

$p2/p1$: The ratio of the pressure downstream of the expansion wave to the upstream pressure.

T_2/T_1 : The ratio of the temperature downstream of the expansion wave to the upstream temperature.

V_2/V_1 : The ratio of the velocity downstream of the expansion wave to the upstream velocity.

ρ_2/ρ_1 : The ratio of the density downstream of the expansion wave to the upstream density.